

User Manual Clarion Mobile Map Navigation software for Clarion NP509 (System Mode)

NP509

Copyright note

The product and the information contained herein is subject to change without prior notification.

This manual may not, in whole or in part, be reproduced or transmitted in any form either electronically or mechanically, including photocopying and recording, without the express written consent of Clarion.

© 2008 - Clarion

Data Source © 2006 Tele Atlas N.V.

All rights reserved.

Thank you for choosing the Clarion NP509 as your in-car navigator. This document is the detailed description of the software when connected to a Clarion Multi Media Station (System mode). When you have a different display that you connected your Clarion NP509 to, please, refer to the separate document describing the Stand-alone operating mode of Clarion Mobile Map.

You can easily discover Clarion Mobile Map while you are using it; however, we still recommend that you read this manual to understand the screens and the features of Clarion Mobile Map.

Table of contents

1 Warnings and Safety information	7
2 Getting started with Clarion Mobile Map	8
2.1 Simple and Advanced modes	
2.2 Buttons and other controls on the screen	
2.2.1 Using keyboards	
2.3 Using the map	
2.3.1 Checking the details of a map location	
2.3.2 Manipulating the map	
2.3.3 Lane information and Signposts	
2.3.4 Status information and hidden controls on the map	
2.3.5 Using the Cursor (the selected map location)	
2.4 Clarion Mobile Map concepts	
2.4.1 Smart Zoom	
2.4.2 Position markers	
2.4.2.1 Current GPS position and Lock-on-Road	
2.4.2.2 Returning to normal navigation	
2.4.2.3 Selected location (Cursor)	
2.4.2.4 Original position in the Cursor menu	
2.4.3 Daytime and night color profiles	
2.4.4 Color scheme in tunnels	22
2.4.5 Route calculation and recalculation	22
2.4.6 Itinerary	23
2.4.7 Track Logs	24
2.4.8 Route demonstration	24
2.4.9 POI (Points of Interest)	25
2.4.10 Road Safety Cameras	25
2.4.10.1 Camera types	
2.4.10.2 Camera directions	27
2.4.11 Speed limit warning	27
3 Navigating with Clarion Mobile Map	28
3.1 Selecting the destination of a route	28
3.1.1 Selecting the Cursor as the destination	
3.1.2 Entering an address or part of an address	
3.1.2.1 Entering an address	
3.1.2.2 Entering an address if house numbering is restarted	
3.1.2.3 Entering an address without knowing the district/suburb	32
3.1.2.4 Selecting an intersection as the destination	33
3.1.2.5 Selecting a city center as the destination	34
3.1.2.6 Entering an address with a ZIP code	35
3.1.2.7 Tips on entering addresses quickly	36

3.1.3 Selecting the destination from your Favorites	36
3.1.4 Selecting the destination from the POIs	36
3.1.5 Selecting the destination with saved POI search criteria	38
3.1.6 Selecting the destination from the History	38
3.1.7 Selecting the destination by entering its coordinates	38
3.2 Creating a multi-point route (inserting a via point)	39
3.3 Creating a multi-point route (appending a new destination)	40
3.4 Editing the route	40
3.5 Viewing the entire route on the map (Fit-to-Screen)	41
3.6 Watching the simulation of the route	41
3.7 Enabling Safety Mode	41
3.8 Pausing the active route	
3.9 Deleting the next via point from the route	42
3.10 Deleting the active route	42
3.11 Using Track Logs	
3.12 Saving the active route	
3.13 Loading a saved route	44
4 Reference Guide (Advanced mode)	45
4.1 Map screen	45
4.1.1 Icons on the map	
4.1.1.1 GPS position quality and Vehicle type indicator	
4.1.1.2 Status indicator strip	49
4.1.1.3 Next two route events (Turn Preview fields)	49
4.1.2 Objects on the map	50
4.1.2.1 Streets and roads	50
4.1.2.2 3D object types	
4.1.2.3 Elements of the active route	
4.1.3 Detour menu	
4.1.4 Cursor menu	
4.1.5 Position menu	
4.1.6 Route Information screen	
4.1.7 Trip Information screen	
4.1.7.1 Trip Computer screen	
4.1.8 Quick menu	
4.1.9 GPS Data screen	
4.2 Find menu	59
4.3 Route menu	
4.4 Manage menu	
4.4.1 Manage Saved Routes	
4.4.2 Manage History	
4.4.3 Manage Track Logs	62

6 En	d User License Agreement	. 76
5 Gl	ossary	. 74
	4.5.9 Track Log settings	73
	4.5.8 Device settings	72
	4.5.7 Menu settings	72
	4.5.6 Warning settings	71
	4.5.5 Navigation settings	70
	4.5.4 Regional settings	69
	4.5.3 Route Planning options	68
	4.5.2 Sound settings	67
	4.5.1 Map Screen settings	66
4.5	Settings menu	65
	4.4.7 User Data Management	65
	4.4.6 Manage Saved Search Criteria	64
	4.4.5 Manage POIs	63
	4.4.4 Manage Favorites	63

1 Warnings and Safety information

Clarion Mobile Map is a navigation system that helps you find your way to your destination with its GPS receiver. Clarion Mobile Map does not transmit your GPS position; others cannot track you.

It is important that you look at the display only when it is safe to do so. If you are the driver of the vehicle, we recommend that you operate Clarion Mobile Map before you start your journey. Plan the route before your departure and stop if you need to change something in the route.

Clarion Mobile Map has a Safety Mode: if you turn on Safety Mode, you cannot change anything in Clarion Mobile Map while the vehicle is moving at a speed of 10 km/h (6 mph) or higher. Unless only passengers operate Clarion Mobile Map, we strongly encourage you to turn on Safety Mode.

You must obey the traffic signs and follow the road geometry. If you deviate from the route that Clarion Mobile Map recommended. Clarion Mobile Map changes the instructions accordingly.

Never place any part of the navigation system where it obstructs the driver's view, where it is in the deployment zone of an airbag or where it might cause injuries in an accident.

For more information, consult the End User License Agreement (page 76).

2 Getting started with Clarion Mobile Map

Clarion Mobile Map is optimized for in-car use. You can use it easily by tapping the screen buttons and the map with your fingertips.

Clarion Mobile Map can plan routes throughout the whole installed map set; you do not need to change maps or switch to a poorly detailed general map to navigate between map segments or countries.

Tasks	Instructions					
Double tapping the screen	You do not need to tap the screen twice for any action. With buttons and controls, a single tap is enough.					
Tapping and holding the screen	You do not need this to access the basic navigation functions. Tap and keep pressing the following buttons to reach extra functions:					
	Tap and hold on the Map screen: you can set the minimum and maximum zoom level of Smart Zoom.					
	Tap and hold any of the Map screen: you can set or reset the zoom value of the button (2D map).					
	Tap and hold any of the Map screen: you can set or reset the tilt and zoom values of the button (3D map).					
	Tap and hold on list and menu screens: the Navigation menu appears.					
	Tap and hold any of the buttons on the Map screen: you can rotate, tilt or scale the map continuously.					
	Tap and hold on keyboard screens: you can delete several characters quickly.					
	Tap and hold continuously. In long lists: you can scroll pages					
	Tap and hold the buttons in the Quick menu to open screens related with the function of the button from the Manage menu or the Settings menu.					

Tasks	Instructions					
Gestures (drag&drop)	You do not need gestures to access the basic navigation features. You need to drag and drop the screen only in cases like:					
	Moving the handle on a slider.					
	Shortcut to open the Map screen: slide your finger from the bottom right corner to the bottom left corner on any screen.					
	Shortcut to open the Navigation menu: slide your finger from the top left corner to the bottom left corner on any screen.					

Start using Clarion Mobile Map

When Clarion Mobile Map is started the first time, you need to do the following:

- Select the written language of the application interface. Later you can change it in Settings (page 69).
- Select the language and speaker used for voice guidance messages. Later you can change it in Settings (page 69).
- 3. Read and accept the End User License Agreement (page 76).
- 4. Select whether to start the program in Simple mode or in Advanced mode. Later you can switch between the two operating modes in Settings.
- 5. Read and accept the road safety warning.

After this, the Navigation menu appears and you can start using Clarion Mobile Map.

The Navigation menu in Simple mode:



The Navigation menu in Advanced mode:



The typical way of using Clarion Mobile Map is to select a destination, and start navigating. You can select your destination in the following ways (not all of them are available in Simple mode):

- Use the selected location on the map (the Cursor) (page 28).
- Enter a full address or a part of an address, for example a street name without a house number or the names of two intersecting streets (page 29).
- Enter an address with ZIP code (page 35). This way you do not need to select the name of the city and the search for street names might be faster as well.
- Use a coordinate (page 38)

- Use a saved location:
 - a Favorite (page 36)
 - a POI (page 36)
 - the History of previously set destinations and waypoints (page 38)

2.1 Simple and Advanced modes

The two operating modes of Clarion Mobile Map mainly differ in the menu structure and the number of available features. The controls and screen layouts are the same.

- Simple mode: you have easy access to the most important navigation functions and the basic settings only. The rest of the settings are set to values that are optimal for typical use.
- Advanced mode: you have access to the full functionality of Clarion Mobile Map.

To switch from Simple mode to Advanced mode: on the startup screen (Navigation Menu), tap

Settings

Advanced Mode



To switch from Advanced mode to Simple mode: on the startup screen (Navigation Menu), tap

Simple Mode

The features and settings available in each mode are as follows:

Type of action	Available in Simple mode	Available in Advanced mode	Explanation
Navigating to a selected map point	Yes	Yes	See page 28
Navigating to a street address	Yes	Yes	See page 29
Navigating to an incomplete address	Yes	Yes	See page 29
Navigating to an intersection	Yes	Yes	See page 33
Navigating to recent destinations (History)	Yes	Yes	See page 38
Navigating to Favorites	Yes	Yes	See page 36
Navigating to a POI	Yes	Yes	See page 36
Navigating to coordinates	No	Yes	See page 38
Creating a multi-point route	No	Yes	See page 39
Saving a map point as a Favorite destination	Yes	Yes	See page 52
Saving a map point as a POI	No	Yes	See page 52
Saving a map point as a location of a Road Safety Camera	No	Yes	See page 52
Mark a map point with a Pin	No	Yes	See page 52
Saving the active route	No	Yes	See page 44
Saving Track Logs	No	Yes	See page 24
Map Screen settings	Only color profiles (from Quick Menu)	Yes	See page 66

Type of action	Available in Simple mode	Available in Advanced mode	Explanation
Menu settings	Only background picture	Yes	See page 72
Sound settings	Yes (from Quick Menu)	Yes	See page 67
Route Planning options	Yes	Yes	See page 68
Regional settings	Only language selection	Yes	See page 69
Warnings	No	Yes	See page 71

2.2 Buttons and other controls on the screen

When you are using Clarion Mobile Map, you usually tap buttons on the touch screen.

You only need to confirm selections or changes in Clarion Mobile Map if the application needs to restart, it needs to perform a major reconfiguration, or you are about to lose some of your data or settings. Otherwise, Clarion Mobile Map saves your selections and applies the new settings without confirmation as soon as you use the controls.

Туре	Example	Description	How to use it
Button	Info	Tap it to initiate a function, to open a new screen, or to set a parameter.	Tap it once.
Icon	⊁ ☆	Shows status information.	Some icons also function as a button. Tap them once.
List	English (US) Español (MX) Français	When you need to select from several options, they appear in a list.	with the and buttons and tap the value that you want.
Slider		When a feature has several different unnamed values, Clarion Mobile Map shows an indicator on a gauge that displays and sets a value from a range.	Drag the handle to move the slider to its new position. Tap the slider where you want the handle to appear; the thumb jumps there.

Type	Example)		Description	How to use it
Switch								When there are only two choices, a checkmark shows whether the feature is enabled.	Tap it to turn the switch on or off.
Virtual	New York, NY, United States <enter name="" street=""> >100 ←</enter>				ted States	×	00 -	Alphabetic and	Each key is a touch screen button.
keyboard	A	В	С	D	E	F	G	alphanumeric keyboards to	screen button.
	Н	I	J	K	L	м	N	enter text and numbers.	
	0	P	Q	R	S	Т	U		
	V	W	x	Y	Z	Sp	ace		
	+		aA .	1//	us Engli	sh (ABCD)	Done		

2.2.1 Using keyboards

You only need to enter letters or numbers in Clarion Mobile Map when you cannot avoid it. You can type with your fingertips on the full-screen keyboards and you can switch between various keyboard layouts, for example ABC, QWERTY, or numerical.

Task	Details
Switching to another keyboard layout, for example from an English QWERTY keyboard to a Greek keyboard	
,	Clarion Mobile Map remembers your last keyboard choice and offers it the next time you need to enter data.
Correcting your entry on the keyboard	Tap to remove the unneeded character(s). Tap and hold the button to delete the entire input string.
Entering a space, for example between a first name and a family name or in multi-word street names	Space
Entering lowercase or capital letters	Tap to cycle through entering lowercase letters, initial capitals or all capitals.
Entering symbols	Tap to switch to a keyboard offering symbol characters.
Finalising the keyboard entry	Tap Done

2.3 Using the map

The map screen is the most frequently used screen of Clarion Mobile Map. It can be accessed from

the Navigation menu by tapping



For further information about the map screen, see page 45.

2.3.1 Checking the details of a map location

• If you are interested in the details of your current position during navigation:


Map

- Check the bottom line of the map. It shows the current street and house number information.
- 2. For further details, tap Position to open the Position menu.
- 3. Tap Info ... The address, the coordinate and the list of nearby POIs will be displayed.
- You can check the details of any other location by selecting it on the map:
 - 1. Tap the map anywhere to open the map control buttons.
 - 2. Tap the desired location on the map. The Cursor () appears there. The address of the location is displayed at the bottom of the map.
 - 3. For further details, tap Cursor to open the Cursor menu.
- It is even easier if you select the desired point in the Find menu. Then the Cursor menu opens
 automatically. You only need to tap the
 button.

2.3.2 Manipulating the map

Position markers on the map:

Current GPS position: (page 21



The following controls help you modify the map view to suit your actual needs the best. Most of these controls appear only if you tap the map once, and disappear after a few seconds of inactivity.

Action	Button(s)	Description
Moving the map	No buttons	You can move the map into any direction. Tap the map at any desired location. The point you hit on the map moves to the center of the screen. If GPS position is available and you have moved the
		map, the button appears. Tap this button to return to the GPS position.
Opening/closing map control buttons	** O	Tap this button to show or hide the following map control buttons:
		Zoom in/out
		Rotate left/right (3D map only)
		Tilt up/down (3D map only)
		Zoom preset buttons (2D map only)
		Tilt and zoom preset buttons (3D map only)
		Return to GPS position button
		Smart Zoom button
Zooming in and out	+ -	Changes how much of the map is displayed on the screen.
	,	Clarion Mobile Map uses high-quality vector maps that let you see the map at various zoom levels, always with optimized content. It always displays street names and other text with the same font size, never upsidedown, and you only see the streets and objects that you need.
		Map scaling has different limits in 2D and in 3D map view modes.
Tilting up and down	+ +	Changes the vertical view angle of the map in 3D mode.
Rotating left and right	+ +	Changes the horizontal view angle of the map in 3D mode.
		When GPS position is available, Clarion Mobile Map always rotates the map so its top faces your direction of travel (Track-Up orientation). You can turn away from Track-Up with these buttons.
		If GPS position is available and you have rotated the
		map, the button appears. Tap this button to re- enable the automatic map rotation.

Action	Button(s)	Description
Viewing modes	2D , 3D , 2D	Gives you the following map perspectives in Clarion Mobile Map:
		 classic top-down view (2D), the top of the map always faces North
		top-down view (2D), the top of the map always points in the current driving direction
		perspective view (3D) the top of the map always points in the current driving direction
		The icon always shows the mode the button switches
		to: If you are in 3D mode, you can see the button and you need to tap it to switch to 2D mode.
Smart Zoom		Clarion Mobile Map can automatically rotate, scale and tilt the map and give you the optimal view:
		When you are approaching a turn, Clarion Mobile Map zooms in and raises the view angle to let you easily recognize your maneuver at the next junction.
		If the next turn is at a distance, Clarion Mobile Map zooms out and lowers the view angle to show you the road in front of you.
		Tap this button once to enable Smart Zoom.
		<u>Tap&hold the button</u> to set the zoom limits of Smart Zoom.
Returning to normal navigation (back to the GPS position with automatic map rotation)	(A)	Tap this button to move the map back to the current GPS position. If the map has been rotated, automatic map rotation is also re-enabled.
Zoom preset buttons (available in Advanced mode only)	B 0	Tap one of the preset buttons to set the zoom level to a fix, predefined value. Smart Zoom is disabled. These buttons are available in 2D mode. Tap&hold any of the buttons to set its value to the
		current zoom level, or to reset it to its original value.
Tilt and zoom preset buttons (available in Advanced mode only)	ΛΔΩ	Tap one of the preset buttons to set the tilt and zoom levels to fix, predefined values. Smart Zoom is disabled. These buttons are available in 3D mode.
		<u>Tap&hold any of the buttons</u> to set its value to the current tilt and zoom levels, or to reset it to its original value.
Map scale	250 m 500 m	Clarion Mobile Map shows the scale of the map in 2D mode.

Action	Button(s)	Description
Fit-to-screen	Fit to Screen	This button does not appear on the Map screen. It is available on the following screens:
		Plan on Map screen: When you have an active route, you can display it in its full length on the map.
		Track Information screen: A track log can be displayed in its full length on the map.
Repeat Voice Instruction	~	Tap this button to repeat the current voice instruction. The distance is updated to always describe the current situation.

2.3.3 Lane information and Signposts

When navigating on multilane roads, it is important to take the appropriate lane in order to follow the recommended route. If lane information is available in the map data, Clarion Mobile Map displays the lanes and their directions using small arrows either at the bottom or at the top of the map (the position of these arrows can be modified in Map Screen settings). Arrows in yellow represent the lanes you need to take.

Where there is additional information available, signposts substitute arrows. Signposts are always displayed at the top of the map. The color and style of the signposts are similar to the real ones you can see above road or by the roadside. They show the available destinations and the number of the road the lane leads to.

All signposts look similar when cruising (when there is no recommended route). When navigating a route, only that signpost is displayed in vivid colors that points to the lane(s) to be taken; all others are darkened out.





2.3.4 Status information and hidden controls on the map

The following information appears in the rounded field in the top left corner, the Turn Preview field. When tapping this area, the result depends on the information currently shown.

lcon	Information	Details	Action
	Irouto in Simple mode	If there is no route to be navigated in Simple mode, this icon appears in the Turn Preview field.	Tap this area to open Find Address.
	There is no active route in Advanced mode	If there is no route to be navigated in Advanced mode, this icon appears in the Turn Preview field.	Tap this area to open Find.

lcon	Information	Details	Action
	There is no valid GPS position.	If an active route exists, and there is no valid GPS position, the view of the sky above you is shown with colored dots for each satellite. Some dots need to turn green to be able to navigate.	Tap this area to open the Route Information screen.
	If the icon is a static picture, route calculation is needed	GPS position and an active route are available, but automatic off-route recalculation is switched off, and you deviated from the route.	Tap this area to make Clarion Mobile Map recalculate the recommended route.
0	If the icon is animated, route calculation is in progress	Clarion Mobile Map is calculating or recalculating the route.	Nothing happens if you tap this area of the screen.
260° 190° 190°	Next route event (next maneuver)	GPS position and an active route are available, and you navigate the recommended route. This area gives you information about the type and distance of the next route event.	Tap this area to open the Route Information screen.

The following area appears next to the above described rounded area. When tapping this area, the result depends on the information currently shown.

Icon	Information	Details	Action
<i>≸</i> k×	There is no valid GPS position	If there is no valid GPS position, this symbol appears here.	Tap this area to open the GPS Data screen to check the signal status or the connection settings.
•	Traffic restriction	When GPS position is available but there is no route to be navigated, the traffic restriction of the upcoming intersection is shown here if there is any.	Nothing happens if you tap this area of the screen.
670 yd , 220 yd	Second route event (maneuver after the next maneuver)	When GPS position and an active route are both available, this field shows the route event that follows the next route event shown in the above described area.	Tap this area to open the Itinerary screen with the turn by turn guidance instructions.
120 yd	Approaching a Road Safety Camera	This icon appears when you are approaching a Road Safety Camera, and the warning for cameras is enabled in Settings.	Tap this area to suppress the audible camera warning. Tap again to display the second route event with the possibility to open the Itinerary.

Icon	Information	Details	Action
Stop	Stops the running simulation	This icon appears during Route Fly Over, Route Simulation, and Track Log playback.	Tap this area to stop the simulation.
22.4%	Route recalculation progress	During route recalculation, this field shows the recalculation progress between 0% and 100%.	Nothing happens if you tap this area of the screen.
*	Indicator strip	S - sounds muted/enabled Track Log recording	Tap this area to open the Itinerary screen with the turn by turn guidance instructions.

The following symbols appear in the Indicator strip:

Icon	Description
*	The sound output of Clarion Mobile Map is muted.
M	The sound output of Clarion Mobile Map is enabled.
	Clarion Mobile Map records a Track log when GPS position is available.
	Track log recording is disabled.

The following information can be seen in the three data fields shown on the map screen. Tap this area to open the Trip Information screen where you can select which values to be shown in these three fields.

When there is no active route, these fields show the following information: current speed, compass and the current time of day.

Icon	Туре	More information	
l sw M l	Compass	Shows the direction of your heading both when the map is automatically rotated (3D) and when the map is always facing North (2D).	
24 mph	Speed information	There are speed values that can be shown:	
		Current speed	
		Speed limit on the current road	

lcon	Туре	More information
1:05	Time information	There are time values that can be shown: Current GPS time Time remaining to reach the destination Time remaining to reach the next via point Estimated arrival time at the destination Estimated arrival time at the next via point
230 yd	Distance information	There are distance type values that can be shown: Distance remaining to reach the destination Distance remaining to reach the next via point Current altitude


The next area is a combined status indicator field. Tap this area to open the Quick menu (page 57).

Icon	Status for	More information
&	GPS position quality	A higher number of lit bars indicates better GPS position accuracy.
A	Vehicle type	The symbol displays the vehicle type used for route calculation.

2.3.5 Using the Cursor (the selected map location)

First, place the Cursor at the desired map location with one of the following options:

 Use the Find menu to select a location. The map returns with the selected point (the Cursor) in the middle, and the Cursor menu appears with the available options.



You can perform the following actions in Simple mode:

Button	Action
Navigate To	Creates a new route with the Cursor as the destination. The previous route (if exists) is deleted.
Add to Favorites	Saves the Cursor as a Favorite destination
Info	Opens a screen with the name, address and coordinate information of the Cursor, and the list of POIs near it

The following options are available in Advanced mode only:

Button	Action
	In the active route, uses the Cursor as the start point by replacing the current GPS position (available in Advanced mode only)

Button	Action
Set as Destination	Creates a new route with the Cursor as the destination. The previous route (if exists) is deleted.
Insert as Via	In the active route, uses the Cursor as a via point (an intermediate destination) preceding the destination (available in Advanced mode only)
Continue	In the active route, uses the Cursor as the destination while keeping the previous destination as a via point (available in Advanced mode only)
Routing Methods	Shows the different routes calculated by the available routing methods. Choose the one that suits your needs the best (available in Advanced mode only)
Place Pin	Marks the map with a Pin at the Cursor (available in Advanced mode only)
Save as POI	Saves the Cursor as a POI (available in Advanced mode only)
Save as Camera	Saves the Cursor as a Road Safety Camera location (available in Advanced mode only)
	This button is not displayed when GPS position is not available or if you are in certain countries where Road Safety Camera warning is prohibited. Even if the button is available, you are responsible for checking whether it is legal to use this feature at your location.

2.4 Clarion Mobile Map concepts

2.4.1 Smart Zoom

Smart Zoom provides much more than just a usual automatic zoom feature:

- While following a route calculated by Clarion Mobile Map: when approaching a turn, it will
 zoom in and raise the view angle to let you easily recognize your maneuver at the next
 junction. If the next turn is at a distance, it will zoom out and lower the view angle to be flat so
 you can see the road in front of you.
- While driving without an active route in Clarion Mobile Map: Smart Zoom will zoom in if
 you drive slowly and zoom out when you drive at high speed.

Enabling Smart Zoom

Tap the map to let the map control buttons appear, and then tap to enable Smart Zoom

Fine-tuning Smart Zoom

Tap the map to let the map control buttons appear, and then tap and hold to open the Smart Zoom Settings window. Modify the zoom limits of Smart Zoom if necessary.

2.4.2 Position markers

2.4.2.1 Current GPS position and Lock-on-Road



When your GPS position is available, Clarion Mobile Map marks your current position with the icon on the map.

The icon may not show your exact GPS position and heading. If roads are near, it is aligned to the nearest road to suppress GPS position errors, and the direction of the icon is aligned to the direction of the road.

To use the current GPS position, tap Position. The Position menu appears and you can save the GPS position as one of the following:

- a Favorite
- a Road Safety Camera
- a POI
- a map marker Pin

2.4.2.2 Returning to normal navigation

When GPS position is available, and you have moved the map (the licon is moving or is not

even visible), or you have rotated the map in 3D mode, the button appears. Tap it to move the map back to the GPS position and re-enable Track-up map orientation (automatic map rotation).

Note! Even if you move the map while you are driving, Clarion Mobile Map continues navigating if there is an active route: it plays the voice instructions and displays the turn preview icons according to your current GPS position.

2.4.2.3 Selected location (Cursor)

If you select a location in the Find menu, or you tap the map, the Cursor appears at the selected point

on the map. Clarion Mobile Map displays the Cursor with a radiating red dot () to make it visible at all zoom levels, even when it is in the background of a 3D map view.

When the Cursor is set, tap warsor. The Cursor menu appears and you can use the Cursor as one of the following:

- the start point of a route
- a via point in a route
- the destination of a route

You can also search for POIs around the Cursor.

Or you can save the location of the Cursor as:

a Favorite

- a Road Safety Camera
- a POI
- a map marker Pin

2.4.2.4 Original position in the Cursor menu

When the Cursor menu is open, a special icon () shows the Cursor position the menu was opened with.

You can move and zoom the map, and you can set the Cursor to a different place. The usual Cursor



To return to the original Cursor position, tap . The map jumps back to the position with which the

Cursor menu was opened, and the icon appears again.

2.4.3 Daytime and night color profiles

Clarion Mobile Map uses different color profiles during the day and during the night.

- · Daytime colors are similar to paper road maps.
- The night color profiles use dark colors for large objects to keep the average brightness of the screen low.

Clarion Mobile Map offers different daytime and night color profiles. It can also switch automatically between the daytime and the night schemes depending on the illumination setting in the Clarion Multi Media Station.

2.4.4 Color scheme in tunnels

When entering a tunnel, the colors of the map change. All buildings disappear, large objects (such as surface waters or forests) and empty areas between roads become black.

However, roads and streets keep their original colors from the daytime or night color scheme currently used.

After leaving the tunnel, the original colors return.

2.4.5 Route calculation and recalculation

Clarion Mobile Map calculates the route based on your preferences:

- · Route calculation method:
 - Fast
 - Short
 - Economical

- Easy
- Vehicle types :
 - Car
 - Taxi
 - Bus
 - Emergency vehicles
- Road types
 - Unpaved Roads
 - Permit Needed
 - Freeways
 - Toll Roads
 - Charge Roads
 - Ferries
 - Cross-border Planning
 - Carpool (appears only when used in the USA)

Clarion Mobile Map automatically recalculates the route if you deviate from the proposed itinerary. For further information about Route Planning options, see page 68.

2.4.6 Itinerary

The Itinerary is the list of the route events, that is, the driving instructions.



When you are on the Map screen, you can display the Itinerary in one of the following ways:

 Tap the area between the Turn preview and the Travel data fields where the symbol of the second next maneuver is displayed (for example 100vd).



You have the following options on the Itinerary screen:

Button	Description
Any of the list items	Opens the map with the selected maneuver in the middle.

Button	Description
Mode	Changes the detail level of the Itinerary. The levels are as follows: Detailed Instructions: all intersections are listed
	Itinerary: only significant intersections (the ones announced in voice guidance) are listed
	Road list: the list of the roads used while navigating the route
◀, ▶	Moves between pages for additional list items.

When the map is open with a maneuver in the middle:

Button	Description
+	Zooms in the map.
_	Zooms out the map.
⋖ , >	Moves the map to show the previous or next maneuver.
Avoid	Opens a screen where you can avoid a part of the route starting from the selected maneuver.

2.4.7 Track Logs

Clarion Mobile Map can log the track that you drive (page 42).

A Track Log is a recording of how your GPS position changed and it is independent of the route Clarion Mobile Map calculated.

Track Logs can be recorded, renamed, replayed, shown on the map, exported to a memory card in GPX format, and deleted. See page 62.

Independently of the normal track log, you can instruct Clarion Mobile Map to record the native GPS data received from the GPS device. These logs are saved as separate text files on the memory card, and they cannot be shown or replayed in Clarion Mobile Map.

To turn on NMEA/SIRF log saving, tap the following buttons:







2.4.8 Route demonstration

Create NMEA/SIRF Log

A simulation drives you through the route, following the driving instructions (page 41). You can choose from a simulation at high speed or at normal driving speed.

You can use it, for example, to see which bridge Clarion Mobile Map planned for the route; if you do not want to take that bridge, you can avoid it.

Fly Over

Route demonstrations can be started from the Route menu by tapping the

speed simulation) or the

(simulation at normal speed) button.


2.4.9 POI (Points of Interest)

A point of interest (POI) is a location that someone might find useful or interesting. Clarion Mobile Map is delivered with thousands of POIs and you can also create your own POIs in the application.

POI locations are marked on the map with special icons. POI icons are quite large so you can easily recognize the symbol. The icons are semi-transparent: they do not cover the streets and intersections behind them.

POIs are grouped into several levels of categories and subcategories. The icon of a POI that comes with the map shows the symbol of the POI category. If you save your own POI, you can select an icon for it independently of the POI category you have put it in.

Saving POIs



Managing POIs

You can select which POI groups to show and which ones to hide on the map, and from which zoom levels POI icons are visible. At the same place you can manage your saved POIs. A saved POI can be renamed, moved to a different POI group, its icon can be changed, or a phone number and

additional information can be added to it. Tap the following buttons: Menu,

2.4.10 Road Safety Cameras

The location of a Road Safety Camera is a special POI. These cannot be searched like other POIs, and there is a special proximity warning only for cameras.

Is Clarion NP509 shipped with a built-in database of Road Safety Cameras?	No
Can you upload Road Safety Camera locations from POI Warner?	Yes
Can Road Safety Camera locations be uploaded in a text file?	Yes
Can you save the Cursor as the location of a Road Safety Camera?	Yes

You can use the POI Warner update tool that is on the enclosed DVD. The first update of fixed Road Safety Cameras is free of charge.

Saving Road Safety Cameras

To save the location of a Road Safety Camera, place the Cursor () at the desired location, then tap the following buttons:

More Options...

Notel

This button is not displayed when GPS position is not available or if you are in certain countries where Road Safety Camera warning is prohibited. Even if the button is available, you are responsible for checking whether it is legal to use this feature at your location

Camera warning

The warning for Road Safety Cameras can be turned on in Warning Settings. Tap the following

buttons: M

ttings

Warnings

Speed Camera Warning

When you approach a Road Safety Camera with the warning enabled, the following happens:

- Visible Warning: The type and distance of the camera is displayed in the secondary Turn
 Preview field (for example
- Audible Warning: If there is no speed limit specified for the camera, or your speed is under the specified speed limit, single beeps warn you about the camera.
- If you exceed the speed limit of the camera, the following also happens:
 - Visible Warning: A symbol with the speed limit appears in the corner of the map (for example: 55).
 - Audible Warning: A special alert sound is played.

2.4.10.1 Camera types

There are different types of Road Safety Cameras.

Icon	Type	Description
	Fixed	Some speed cameras stand by the roadside, looking in one direction, measuring one or both directions of the traffic. They measure your current speed. For these speed cameras you can specify the controlled traffic direction and the speed limit. Clarion Mobile Map warns you when you approach these speed cameras in the measured direction. If your speed exceeds the speed limit near the speed camera, Clarion Mobile Map plays a special warning sound.
	Mobile	Some speed cameras are operated from vehicles. They do not always work and they are not set to check a preset speed limit. The warning is similar to fixed speed cameras, but as there is no speed limit given, only the proximity is announced.
.	Built-in	Some speed cameras are built into traffic lights. They work like fixed speed cameras, but they are difficult to spot. The warning for proximity and speeding is the same as for the fixed speed cameras.

Icon	Туре	Description
Section control	Section control	These speed cameras work in pairs, and do not measure your current speed but your average speed between the two speed cameras. Both identify your car and record the exact time you pass them. They use the difference between the two points in time to calculate your average speed.
	Clarion Mobile Map warns you when you approach one of these speed cameras, but as you pass by, the warning stays on, and your average speed is measured until you reach another speed camera of this type. If your average speed exceeds the speed limit between the two speed cameras, you receive the same special warning sound as with the other speed camera types.	
		In the rare case Clarion Mobile Map cannot register the moment you pass the second speed camera (for example, it is placed at the exit of a tunnel where GPS position is not yet available) the warning continues. Just tap the speed camera symbol displayed on the screen to stop the warning.
		Tap again to display the second route event with the possibility to open the Itinerary.
	Red light	These cameras check if you obey traffic lights. The warning is similar to mobile speed cameras: as there is no speed limit given, only the proximity is announced.

2.4.10.2 Camera directions

A speed camera can measure the speed of one direction of the traffic, both directions, or even several directions in an intersection, when they are mounted on a rotating base. The same directions apply to red light cameras. Clarion Mobile Map warns you only if you drive in a measured or possibly measured direction. The measured direction of the camera appears with the following symbols:

lcon	Description
	The camera checks speed in the direction into which you are driving.
	The camera checks speed in the opposite driving direction.
	The camera checks speed in both directions on the road.
×	The camera can check speed in any direction.

2.4.11 Speed limit warning

Maps sometimes contain information about the speed limits of the road segments. This information may not be available for your region (ask your local dealer) or may not be fully correct for all roads on the map.

You can configure Clarion Mobile Map to warn you if you exceed the current limit. Tap the following



When you exceed the speed limit, a voice message is played using the selected voice guidance profile.

3 Navigating with Clarion Mobile Map


You can set up your route in Clarion Mobile Map in several ways:

- if you need a simple route (a route with only one destination, without any intermediate via points), you can select the destination and start navigating to it right away
- you can plan a multi-point route (available in Advanced mode only)
- you can also plan a route independently of your current GPS position or even without GPS reception (available in Advanced mode only)

3.1 Selecting the destination of a route

Clarion Mobile Map offers you several ways of choosing your destination and via points (intermediate destinations):

- Use the selected location on the map (the Cursor) (page 28).
- Enter a full address or a part of an address, for example a street name without a house number or the names of two intersecting streets (page 29).
- Enter an address with ZIP code (page 35). This way you do not need to select the name of the city and the search for street names might be faster as well.
- Use a coordinate (page 38)
- Use a saved location:
 - a Favorite (page 36)
 - a POI (page 36)
 - the History of previously set destinations and waypoints (page 38)



3.1.1 Selecting the Cursor as the destination

- Locate your destination on the map: move and scale the map as needed (page 13).
- 2. Tap the location that you want to select as your destination. The Cursor () appears.
- 3. Tap Cursor to open the Cursor menu.
- 4. The map appears with the selected point in the middle. Tap

 We Set as Destination (Advanced mode) from the Cursor menu. The route is then automatically calculated, and you can start navigating.



If you know that you will use a destination later, when the Cursor menu appears, save it as a POI (in Advanced mode only), or put it on the list of your Favorites first. The Cursor menu returns automatically with the same point. Now you can use it as a route point.

3.1.2 Entering an address or part of an address

If you know at least a part of the address, it is the quickest way to select the destination of the route.

Using the same screen, you can find an address by entering:

- · the exact address, including house number
- the center of a city
- an intersection
- the midpoint of a street
- any of the above, starting the search with the ZIP code (page 35)

3.1.2.1 Entering an address

The parts of the address are shown on buttons. Start reading from the top, and if you want to change any of them, tap the button.



- 1. Tap the following buttons: (Simple mode), or Find Address (Advanced mode).
- By default, Clarion Mobile Map proposes the country, state and city where you are. If needed, tap the button with the name of the country, and select a different one from the list. If you select
- a new country, you also need to select the state, or tap regardless of the state it is in.
- 3. If needed, change the city:
 - To select the city from the list of recently used ones, tap the button
 - To enter a new city:
 - Tap the button with the name of the city, or if you have changed the country/state, tap

 City Name>
 ...
 - 2. Start entering the city name on the keyboard.
 - 3. Get to the list of search results:

- After entering a couple of characters, the names that match the string appear in a list.
- Tap ______ to open the list of results before it appears automatically.
- Select the city from the list.
- Enter the street name:
 - <Street Name>
 - 2. Start entering the street name on the keyboard.
 - Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap

 Done
 to open the list of results before it appears automatically.
 - Select the street from the list.
- Enter the house number:
 - < House Number>
 - 2. Enter the house number on the keyboard. (To enter letters, tap select an alphabetic keyboard layout. To enter symbols, tap 1/!
 - 3. Tap Done to finish entering the address.
- 6. The map appears with the selected point in the middle. Tap

 W Set as Destination (Advanced mode) from the Cursor menu. The route is then automatically calculated, and you can start navigating.


3.1.2.2 Entering an address if house numbering is restarted

There are long roads where house numbering is restarted at some point. This way the same house number can appear twice or even more times on the same road. If this is the case, after entering the house number, you need to select the appropriate address by the district/suburb information.

- 1. Tap the following buttons: (Simple mode), or Find Address (Advanced mode).
- 2. By default, Clarion Mobile Map proposes the country/state and city where you are. If needed, tap the button with the name of the country/state, and select a different one from the list.
- 3. If needed, change the city:
 - To select the city from the list of recently used ones, tap the button.


- To enter a new city:
 - Tap the button with the name of the city, or if you have changed the country/state, tap

 City Name>
 ...
 - 2. Start entering the city name on the keyboard.
 - 3. Get to the list of search results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap
 to open the list of results before it appears automatically.
 - Select the city from the list.
- 4. Enter the street name:




- 2. Start entering the street name on the keyboard.
- 3. Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap

 Done
 to open the list of results before it appears automatically.
- 4. Select the street from the list.
- 5. Enter the house number:



- 2. Enter the house number on the keyboard. (To enter letters, tap select an alphabetic keyboard layout. To enter symbols, tap 1/!
- 3. Tap Done to finish entering the address.
- 6. A list appears with the matching addresses. Tap the desired one.



3.1.2.3 Entering an address without knowing the district/suburb


Long roads can run across several districts or suburbs. You may not know what particular house number is located where. In this case, follow the instructions below:



- By default, Clarion Mobile Map proposes the country/state and city where you are. If needed, tap the button with the name of the country/state, and select a different one from the list.
- 3. If needed, change the city:
 - To select the city from the list of recently used ones, tap the button
 - To enter a new city:
 - Tap the button with the name of the city, or if you have changed the country/state, tap

 City Name>
 .
 - 2. Start entering the city name on the keyboard.
 - 3. Get to the list of search results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap
 automatically.

 Done
 to open the list of results before it appears
 - 4. Select the city from the list.
- Enter the street name:



- 2. Start entering the street name on the keyboard.
- 3. Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap
 To open the list of results before it appears automatically.
- 4. Instead of selecting one of the streets, tap
- Enter the house number:

 - 2. Enter the house number on the keyboard. (To enter letters, tap and select an alphabetic keyboard layout. To enter symbols, tap 1/!

- 3. Tap to finish entering the address.
- 6. A list appears with the matching addresses. Tap the desired one.
- 7. The map appears with the selected point in the middle. Tap Set as Destination (Simple mode) or (Advanced mode) from the Cursor menu. The route is then automatically calculated, and you can start navigating.

3.1.2.4 Selecting an intersection as the destination




- By default, Clarion Mobile Map proposes the country/state and city where you are. If needed, tap the button with the name of the country/state, and select a different one from the list.
- 3. If needed, change the city:
 - To select the city from the list of recently used ones, tap the button
 - To enter a new city:
 - Tap the button with the name of the city, or if you have changed the country/state, tap

 City Name>
 ...
 - 2. Start entering the city name on the keyboard.
 - 3. Get to the list of search results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap
 to open the list of results before it appears automatically.
 - 4. Select the city from the list.
- Enter the street name:
 - <Street Name>
 - 2. Start entering the street name on the keyboard.
 - 3. Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap

 To pen the list of results before it appears automatically.
 - Select the street from the list.
- 5. Tap the button.

- If only a few intersecting streets exist, their list appears immediately.
- In case of a longer street, a keyboard screen appears. Start entering the name of the
 intersecting street on the keyboard. As you type, if the matching streets can be shown
 on one screen, their list appears automatically.
- 6. Tap the desired intersecting street in the list.



3.1.2.5 Selecting a city center as the destination

The City Center is not the geometric center of the city but an arbitrary point the map creators have chosen. In cities and villages, it is usually the most important intersection; in larger cities, it is an important intersection.


The procedure is explained starting from the Navigation menu.

- 1. Tap the following buttons: (Simple mode), or Find Address (Advanced mode).
- By default, Clarion Mobile Map proposes the country/state and city where you are. If needed, tap the button with the name of the country/state, and select a different one from the list.
- 3. If needed, change the city:
 - To select the city from the list of recently used ones, tap the button
 - To enter a new city:

City Center

- Tap the button with the name of the city, or if you have changed the country/state, tap

 City Name>
- 2. Start entering the city name on the keyboard.
- 3. Get to the list of search results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap to open the list of results before it appears automatically.
- 4. Select the city from the list.



3.1.2.6 Entering an address with a ZIP code


All of the above address searching possibilities can be performed with entering the ZIP code instead of the city name. Find below an example with a full address:



- By default, Clarion Mobile Map proposes the country/state and city where you are. If needed, tap the button with the name of the country/state, and select a different one from the list.
- 3. Tap the button with the name of the city, and enter the ZIP code:
 - Start entering the ZIP code on the keyboard.
 - 2. Get to the list of results:
 - After entering a couple of numbers, matching results appear in a list.
 - Tap

 Done

 to open the list of results before it appears automatically.
 - 3. Pick the city from the list.
- 4. Enter the street name:



- 2. Start entering the street name on the keyboard.
- Get to the list of results:
 - After entering a couple of characters, the names that match the string appear in a list.
 - Tap
 to open the list of results before it appears automatically.
- Select the street from the list.
- 5. Enter the house number:



- 2. Enter the house number on the keyboard. (To enter letters, tap and select an alphabetic keyboard layout. To enter symbols, tap 1/!
- 3. Tap Done to finish entering the address.
- 6. The map appears with the selected point in the middle. Tap

 We set as Destination (Advanced mode) from the Cursor menu. The route is then automatically calculated, and you can start navigating.

3.1.2.7 Tips on entering addresses quickly

- When you are entering the name of a city or a street, Clarion Mobile Map only displays those characters that appear in possible search results. The other characters are graved out.
- When entering the city name or the street name, tap the of letters; Clarion Mobile Map lists the items that contain the specified letters.
- You can speed up finding an intersection:
 - Search first for the street with a less common or less usual name; fewer letters are enough to find it.
 - If one of the streets is shorter, search for that one first. You can then find the second one faster.
- You can search for both the type and the name of a road. If the same word appears in several
 names, for example in the name of streets, roads and avenues, you can obtain the result faster
 if you enter the first letter of the street type: For example, enter Pi A to obtain Pine Avenue
 and skip all Pine Streets and Pickwick Roads.
- You can also search in ZIP codes. This is useful when a street name is common and it is used
 in several districts of a city.


3.1.3 Selecting the destination from your Favorites

You can select a location that you have already saved as a Favorite to be your destination.

The procedure is explained starting from the Navigation menu.



2. Tap the Favorite that you want to set as your destination.



3.1.4 Selecting the destination from the POIs

You can select your destination from the POIs included with Clarion Mobile Map or from the ones you have previously created.

The procedure is explained starting from the Navigation menu.



2. Select the area around which the POI should be searched for:



The map appears with the Cursor in the middle. Modify the location of the Cursor OK if necessary, then tap The POI will be searched for around the given location. Around GPS Position: The POI will be searched for around the current GPS position. Around Destination The POI will be searched for around the destination of the active route. Along Route The POI will be searched for not around a given point, but by the size of the detour it adds to the active route. This can be useful if you search for a later stopover that causes only a minimal detour, for example upcoming gas stations or restaurants. You can narrow the search with the following: Select the POI group (e.g. Accommodation), and after that, if needed, select the POI subgroup (e.g. Hotel or Motel). Search To find the POI by its name, tap and use the keyboard to enter a part of the name. List All in this Group To list all POIs in a given POI group, tap [optional] When finally the list of results appear, you can sort the list: By Name sort the list alphabetically (available when you search around a single location) Order by Distance sort the list by the distance from your current position in a straight line (available when you search around a single location) Order by sort the list by the distance to drive on route from your current position (available when you search along the active route) Order by Detour sort the list by the size of the needed detour (available when you search along the active route) Tap the desired POI in the list. Select Review the details of the selected item and tap

The map appears with the selected point in the middle. Tap

automatically calculated, and you can start navigating.

Set as Destination

5.

6.

7.

(Simple

Navigate To

(Advanced mode) from the Cursor menu. The route is then


3.1.5 Selecting the destination with saved POI search criteria

POI search criteria can be saved in the POI section of the Manage menu, but Clarion Mobile Map is already shipped with some saved criteria you can use instantly when searching for a POI.

The procedure is explained starting from the Navigation menu.




- 3. Select one of the saved criteria, and the list of matching POIs appears.
- 4. Tap the desired POI in the list.



3.1.6 Selecting the destination from the History

The destinations that you have set earlier appear in the History.

The procedure is explained starting from the Navigation menu.



3.1.7 Selecting the destination by entering its coordinates


This feature is available in Advanced mode only.

The procedure is explained starting from the Navigation menu.




- 2. [optional] Tap Coordinate Display Format to change the format of the displayed coordinates.
- 3. Tap the latitude or longitude value to change the coordinates.

Enter the coordinate values in WGS84 format on the keyboard: the latitude (N or S) and the longitude (E or W).



The map appears with the selected point in the middle. Tap 6



W Set as Destination mode) or (Advanced mode) from the Cursor menu. The route is then automatically calculated, and you can start navigating.

3.2 Creating a multi-point route (inserting a via point)

Multi-point routes are created from simple routes, so a route must be active first. One of the ways of expanding the route is to keep the destination, and to add via points (intermediate destinations).

This feature is available in Advanced mode only.

- Select a new location as you did in the previous sections. This will be the additional destination in the route.
- 2. The map appears with the selected point in the middle, and the Cursor menu opens automatically.
- Insert as Via 3 Tap to add the point as an intermediate destination preceding the final destination of the route.
- [optional] To add more points to the route, repeat the above steps as many times as you like.

If you insert a via point in a route that is already a multi-point route, you will automatically be taken to the Edit Route screen where you can determine the position of the intermediate route point. When you enter the screen, the new via point is placed as the first via point to be reached. The new point is the highlighted point in the list.

You have the following options:

Button	Action
1	The selected point moves up in the list (becomes a via point to be reached earlier). Tap this button repeatedly, and the point becomes the start point of the route (when routing from a given location) or the first via point to reach (when routing from the GPS position).
7	The selected point moves down in the list (becomes a via point to be reached later). Tap this button repeatedly, and the point becomes the final destination of the route.
U	Tap this button to reverse the route. The start point becomes the destination, the destination becomes the start point, and all via points are to be reached in the opposite order than before.
Optimize	Tap this button to optimize the route. The start point and the destination remain at their position, but the via points are reordered to make the shortest possible route.
Remove	Tap this button to remove the selected point from the route. The route remains as it was before adding the new point.

Every time a new point is added, the route is recalculated automatically, and you can start navigating right away.

3.3 Creating a multi-point route (appending a new destination)

destination Multi-point routes are created from simple routes, so a route must be active first. One of the ways of expanding the route is to add a new destination. The previous destination becomes the last via point of the route.

This feature is available in Advanced mode only.

- Select a new location as you did in the previous sections. This will be the additional destination in the route.
- 2. The map appears with the selected point in the middle, and the Cursor menu opens automatically.
- 3. Tap More Options... to open the full Cursor menu with the additional functions.
- 4. Tap to add the point as a new final destination demoting the previous one to the last intermediate destination.
- 5. [optional] To add more points to the route, repeat the above steps as many times as you like.

Every time a new point is added, the route is recalculated automatically and you can start navigating right away.

3.4 Editing the route

This feature is available in Advanced mode only.



The list of route points appear with the start point at the top of the list and the final destination at the bottom. If several via points exist, you might need to scroll between pages.

Tap one of the route points in the list. You have the following options:

Button	Action	
1	The selected point moves up in the list (becomes a via point to be reached earlier). Tap this button repeatedly, and the point becomes the start point of the route (when routing from a given location) or the first via point to reach (when routing from the GPS position).	
7	The selected point moves down in the list (becomes a via point to be reached later). Tap this button repeatedly, and the point becomes the final destination of the route.	
C	Tap this button to reverse the route. The start point becomes the destination, the destination becomes the start point, and all via points are to be reached in the opposite order than before.	
Optimize	Tap this button to optimize the route. The start point and the destination remain at their position, but the via points are reordered to make the shortest possible route.	
Remove	Tap this button to remove the selected point from the route.	

As soon as you leave this screen, the route is recalculated automatically, and you can start navigating right away.

3.5 Viewing the entire route on the map (Fit-to-Screen)

The map can be moved and scaled to show the whole line of the route. You do not need to manipulate the map manually. The Plan on Map feature does it for you.

In **Advanced mode** you have the following options to enter Plan on Map:

Via the Route Information screen using a shortcut: tag



In **Simple mode** the last option is available only.

3.6 Watching the simulation of the route

This feature is available in Advanced mode only.

1

The procedure is explained starting from the Map screen.



- 2. The Route menu appears. There are two ways of running the route simulation:
 - Tap to run the simulation at high speed to give you a quick overview of the route.
 - Tap
 to run the simulation at normal speed and with voice guidance instructions announced. This option is for demonstration purposes, or for checking difficult parts of the route in advance.
 - 3. The simulation can be aborted any time by tapping

3.7 Enabling Safety Mode

This feature is available in Advanced mode only.

Safety Mode disables the touch screen above 10 km/h (6 mph) to keep your attention on the road. While driving, you will not be able to set a new destination or to change settings. The only screen control that remains enabled is the gesture that puts you back on the Map screen.

The procedure is explained starting from the Map screen.

Tap the following buttons: Menu Settings Safety Mode

3.8 Pausing the active route

You do not need to pause the active route: when you start driving again, Clarion Mobile Map restarts the voice instructions from your position.

3.9 Deleting the next via point from the route

The easiest way to delete the upcoming route point (the next via point) is to open the Route Information screen by tapping the Turn Preview field () on the Map screen, and then tapping

Skip Next Via

Skip Next Via





Alternatively, you can do it through the Navigation menu:

3.10 Deleting the active route

The easiest way to delete the active route in both Simple mode and Advanced mode is to open the

Route Information screen by tapping the Turn Preview field (on the Map screen, and then

tapping Delete Route

Manu





In Advanced mode, you have another option. Tap the following buttons:

🖺 Note!

If via points exist in the active route, you cannot delete the route immediately on the Skip Next Via

Route Information screen. Tap

repeatedly until all via points disappear

and the Delete

button appears. Tap it to cancel the whole route.

3.11 Using Track Logs

Clarion Mobile Map can record the track (how your GPS position changed) that you drive.

∜ Tip!

You do not need to select a destination and create a route for this; you can also record your driving path while cruising.

This feature is available in Advanced mode only.

The procedure is explained starting from the Map screen.

Recording the traveled path (creating a Track Log)

- 1. Start driving.
- 2. Tap the following buttons: Menu , Manage , Track Logs
- 3. Start the recording: tap the hutton.

You return to the map and you can continue driving.

4. Repeat the above steps, then tap
Map labels the Track Log with a time stamp.

(As an alternative, you can tap the button in the Quick menu to start, and later to stop the Track Log recording.)

Simulating a Track Log on the map

- 1. Tap the following buttons: Menu Manage Track Logs
- 2. Locate the desired Track Log, and then tap the button next to it.
- 3. The map returns, and the Track Log simulation (a life-like replay) begins.
- 4. You can stop the replay any time by tapping the stop button.

Changing the color of a Track Log

- 1. Tap the following buttons: Menu , Manage , Track Logs
- 2. Tap the desired Track Log and then tap one of the color buttons.

3.12 Saving the active route

This feature is available in Advanced mode only.

The procedure is explained starting from the Map screen.



1. Tap the following buttons:



When you save a route. Clarion Mobile Map not only saves the route points but the whole itinerary:

- If you updated your map since you first saved the route, Clarion Mobile Map recognizes the change, and recalculates the driving instructions according to the latest available map information
- If you want to save the route, you need to save it before you start navigating. During navigation, Clarion Mobile Map deletes any via points that you already left behind together with the road segments used to reach it.

3.13 Loading a saved route

This feature is available in Advanced mode only.

Tap the route you wish to navigate.

The procedure is explained starting from the Map screen.



1. Tap the following buttons: Menu

2.

- 3. In the very likely case when the start position of the saved route is different from the current GPS position, you need to confirm whether you want to stop navigating from the current GPS position to use the start point of the loaded route.
 - If you choose this option, automatic off-route recalculation will be disabled.
 - If you choose to keep the current GPS position as the start point, the route will be recalculated starting from your current position.
- The map appears, and you can start navigating.

4 Reference Guide (Advanced mode)

On the following pages you will find the description of the different menu screens of Clarion Mobile Map in Advanced mode. In Simple mode, these functions work the same way, but only a few of them are available.

The Navigation menu:

Clarion Mobile Map starts with the Navigation menu. From there you can access the following screens:

Screen	Button	Description
Мар	Мар	The Map screen.
Find	Find	Selecting the destination (for example an address or a POI) or using the search engine of Clarion Mobile Map for any other reason (for example to look for the phone number of a POI).
Route	Route	Managing the active route (obtaining information about it, changing or deleting it or parts of it) or planning a route without GPS reception.
Manage	Manage	Managing user data, such as saved locations (POIs, Favorites, Pins, and History items), Saved Routes, and Track Logs.
Settings	Settings	Managing the behavior of Clarion Mobile Map, for example the map layout during navigation, the used languages or the warnings.

4.1 Map screen

Clarion Mobile Map is primarily intended for land navigation. That is why maps in Clarion Mobile Map look similar to paper road maps. However, Clarion Mobile Map provides much more than regular paper maps: you can customize the look and the content of the map.

The most important and most often used screen of Clarion Mobile Map is the Map screen.





During navigation, the screen shows route information and trip data (left screenshot), but when you tap the map, additional buttons and controls appear for a few seconds (right screenshot). Most parts of the screen behave as buttons.

Symbol	Name	Action
85 "	Turn Preview, that is, the next route event	Opens the Route Information screen
220yd	Second upcoming route event	Opens the Itinerary

Symbol	Name	Action
4:04 24 mph 0:02	Trip data	Opens the Trip Information screen
& mmn	GPS position quality	Opens the Quick menu
A	Vehicle used in route calculation	Opens the Quick menu
Top row	Next street or Next city	Additional buttons and controls appear for a few seconds
Bottom row	Current street and house numbers on left and right	Additional buttons and controls appear for a few seconds
2D , 3D , 2D	Map view modes	Switches between 2D and 3D map modes: • 2D North-up • 2D rotated • 3D rotated
Menu	Menu	Opens the Navigation menu
Detour	Detour	Opens the Detour screen, offering two ways of modifying the route: the list of Saved Search Criteria a button to avoid parts of the route
Position	Position menu (appears when navigating a route)	Opens the Position menu
Cursor	Cursor menu (appears when there is no GPS position or the Cursor is not at the current GPS position)	Opens the Cursor menu
** C	Open/Close Map control buttons	Tap this button to show or hide the following map control buttons: • Zoom in/out • Rotate left/right (3D map only) • Tilt up/down (3D map only) • Zoom preset buttons (2D map only) • Tilt and zoom preset buttons (3D map only) • Return to GPS position button • Smart Zoom button

Symbol	Name	Action
+ , +	Rotate left, rotate right	Rotates the 3D map left or right
+ +	Tilt up, tilt down	Tilts the 3D map
+ -	Zoom in, zoom out	Scales the map
(A)	Return to GPS position (appears when GPS position is available and you have moved the map)	Tap this button to move the map back to the current GPS position. If the map has been rotated, automatic map rotation is also re-enabled.
[E-3]	Enable Smart Zoom (replaces the previous button if there is no GPS position or the map has not been moved)	Tap this button once to enable Smart Zoom. Tap&hold the button to set the zoom limits of Smart Zoom.
* 0 C	Zoom preset buttons (available in Advanced mode only)	Tap one of the preset buttons to set the zoom level to a fix, predefined value. Smart Zoom is disabled. These buttons are available in 2D mode.
		<u>Tap&hold any of the buttons</u> to set its value to the current zoom level, or to reset it to its original value.
	Tilt preset buttons (available in Advanced mode only)	Tap one of the preset buttons to set the tilt and zoom levels to fix, predefined values. Smart Zoom is disabled. These buttons are available in 3D mode.
		Tap&hold any of the buttons to set its value to the current tilt and zoom levels, or to reset it to its original value.
	Current GPS position (on nearest road)	n/a
0	Cursor (selected map location)	n/a
7 1	Lane information	n/a
Amsterdam Ave 95 SB Geo Washington Br	Signpost information	n/a
Blue line	Active route	n/a
250 m 500 m	Map scale (2D map only)	n/a

Symbol	Name	Action
SPEED LIMIT 55	Speed limit	n/a
	Repeat Voice Instruction	Tap this button to repeat the current voice instruction. The distance is updated to always describe the current situation.

4.1.1 Icons on the map

There are several status icons on the map. Most of them also function as a button. The information they provide is as follows:

- GPS position quality
- Vehicle type used for route calculation
- Sound status (muted or enabled)
- · Track log recording status

4.1.1.1 GPS position quality and Vehicle type indicator

This area is a multiple status indicator, and also acts as a button that opens the Quick menu.

GPS reception quality shows the current accuracy of the position information.

Icon	Description	
&n	Clarion Mobile Map has no connection to the GPS receiver: GPS navigation is not possible.	
	Devices with a built-in GPS receiver are permanently connected. On such devices, the icon does not appear in normal circumstances.	
&	Clarion Mobile Map is connected to the GPS receiver, but the signal is too weak and the receiver cannot determine the GPS position. GPS navigation is not possible.	
& H11111	Only a few satellites are received. Position information is available, but elevation (altitude) cannot be calculated. GPS navigation is possible, but the position error may be significant.	
8 mm	Altitude information is available, the position is a 3D position. GPS navigation is possible.	

The remaining part of the field shows the vehicle type used for route calculation.

Icon	Vehicle type
女	Car
æ	Taxi

Icon	Vehicle type
\mathbf{Q}	Bus
团	Emergency vehicles

4.1.1.2 Status indicator strip

This is a multiple status indicator. It indicates the following status information on a single strip:

Icon	Description
W	The sound output of Clarion Mobile Map is muted.
M	The sound output of Clarion Mobile Map is enabled.
	Clarion Mobile Map records a Track log when GPS position is available.
	Track log recording is disabled.

4.1.1.3 Next two route events (Turn Preview fields)

There are two fields reserved on the Map screen to display the next two maneuvers (route events that are listed in the Itinerary). Both the type of the event (turn, traffic circle, exiting freeway, etc.) and its distance from the current GPS position is displayed.

Most of these icons are very intuitive and you also know them as road signs. The following table lists some of the frequently shown route events. The same symbols are used in both fields:

Icon	Description
190 _{rt}	Turn left.
61 _{yd}	Turn right.
17 _{rd} 68 yd	Turn back.
160 _{rd}	Bear right.
40 yd 220 yd	Turn sharp left.
580 si 670 yd	Keep left.
300 rd 68 yd	Continue straight in the intersection.
260 _r 31 180yd	Enter traffic circle. The number of the exit is shown in the circle, but only for the next turn.
280 _r	Enter freeway.

Icon	Description
5.5 m 190yd	Exit freeway.
150 _{rd}	Board ferry.
340-d 100yd	Leave ferry.
210 _{rd}	Approaching the next via point.
320rd 330 yd	Approaching the destination.

In certain situations when route events are not important, these fields show other useful pieces of information. They are described here: page 16.

4.1.2 Objects on the map

4.1.2.1 Streets and roads

Clarion Mobile Map shows the streets in a way that is similar to how the paper road maps show them. Their width and colors correspond to their importance: you can easily tell a freeway from a small street.

∜⊤ip! If you prefer not to see street names during navigation, turn them off (page 66).

4.1.2.2 3D object types

Clarion Mobile Map supports the following 3D object types:

Type	Description
3D landmarks	Landmarks are 3D artistic or block representations of prominent or well-known objects. 3D landmarks are only available in selected cities and countries.
Elevation model	Hills and mountains are shown in the background of the 3D map view, and illustrated by color on the 2D map.
Elevated roads	Complex intersections and vertically isolated roads (such as overpasses or bridges) are displayed in 3D.
3D buildings	Full 3D city building data that represents actual building size and position on the map. Building data is limited to the city centers of major cities in the US and Europe.
3D terrain	3D terrain map data shows changes in terrain, elevations or depressions in the land when you view the map, and use it to plot the route map in 3D when you navigate.



To fine-tune 3D visualization on the map, tap the following buttons:

3D Settings

4.1.2.3 Elements of the active route

Clarion Mobile Map shows the route in the following way:

Symbol	Name	Description
	Current GPS position	Your current position displayed on the map. If roads are near, it is aligned to the nearest road.
0	Cursor (selected map location)	The location selected in the Find menu, or a map point selected by tapping the map.
	Start point	The first point of the route.
		Normally if GPS position is available, it is the start point of the route. If there is no valid GPS position, Clarion Mobile Map uses the last known GPS position as the start point.
		When you are using a saved route, Clarion Mobile Map asks you if you want to use your GPS position or the first point in the saved route as the start point.
		You can also modify the start point in the Cursor menu. If you do so, automatic off-route recalculation needs to be turned off to keep the selected point as the start point.
		If automatic off-route recalculation is disabled for any
		of the above, tapping the icon in the Turn Preview field not only initiates route recalculation from the current GPS position, but it will re-enable the automatic off-route recalculation as well.
	Via point	A via point is an intermediate destination. You can place as many via points as you want.
XX	Destination (end point)	The last point of the route, the final destination.
	Route color	The route always stands out with its color on the map, both in daytime and in night color mode. The active leg of the route is always displayed in a brighter shade than the inactive (upcoming) legs.
	Active leg of the route	The section of the route on which you are driving.
		If you have not added any via points (only a destination), the entire route is the active leg. If you have added via points, the active leg is the part of the route from your current location to the next route point (the next via point, or the destination if there are no more via points to reach).
	Inactive legs of the route	The future sections of the route; each of them becomes active when you reach the via point at its beginning.
	Streets and roads that are excluded from the navigation	You can choose whether you want to use or avoid certain road types (page 68). However, when Clarion Mobile Map cannot avoid such roads, the route will include them and it will show them in a color that is different from the route color.

4.1.3 Detour menu

This screen contains quick detour possibilities during navigation. It can be opened directly from the

Map screen by tapping Detour

You have the following options:

- On the main part of the screen you can see the first page of Saved Search Criteria. Select any
 of the criteria to quickly receive the list of nearest matching POIs, and instantly plan a new
 route to the desired one, or insert it as a via point in your active route.
- In Advanced mode more buttons appear at the bottom:
 - Avoid : If you want to bypass a part of the route starting from the next intersection, tap this button, and select a distance to bypass.
 - Delete Avoids: If you have used the above function before, tap this button to clear the restrictions from the map.

4.1.4 Cursor menu

As soon as you select one point in the Find menu, the map appears with the Cursor menu, a menu with possible actions for the selected point.

Alternatively when you tap the map, control buttons appear. Tap again to place the Cursor, a radiating

red dot. Now tap Cursor, and the Cursor menu opens with a list of options.

You can perform the following actions in Simple mode:

Button	Description
+	Closes the Cursor menu, and returns to the previous screen.
_	Zooms out the map.
+	Zooms in the map.
Þ Ö 1	With the Cursor menu open, you can still move or scale the map, and tap the map anywhere to place the Cursor to a new location, but when you use this button, the Cursor jumps back to the place where it was at the time when you opened the Cursor menu.
*	Displayed at the Cursor if it is at the same location with which the Cursor menu was opened.
0	Displayed at the Cursor if it has been relocated since the Cursor menu was opened.
Navigate To	Creates a new route with the Cursor as the destination. The previous route (if exists) is deleted.
Add to Favorites	The location of the Cursor is added to the list of frequently visited destinations, the so called Favorites. You can give a name for the Favorite.
Info	Opens a new screen with the address and coordinate of the Cursor, and the list of nearby POIs.

The following options are available in Advanced mode only:

Button	Description	
Set as Destination	Creates a new route with the Cursor as the destination. The previous route (if exists) is deleted.	
Remove Destination	If the Cursor is at or near the destination, this button replaces the previous one, and deletes the current destination from the route. The last via point is promoted as destination, or if there are no via points, the route is deleted.	
☐ Insert as Via	The Cursor is added to the active route as an intermediate route point, a point to be reached before the destination. If there is already a via point in the route, the Edit Route screen opens to let you decide where the new via point is to appear in the route.	
Remove Via	If the Cursor is at or near one of the via points, this button replaces the previous one, and deletes the selected via point from the route. The route is recalculated without the deleted point.	
Place Pin	Map locations can be marked with Pins. Unlike POIs, a Pin has no name and other details, only a color to let you tell one from another on the map.	
Remove Pin	If the Cursor is at or near a Pin, this button replaces the previous one, and deletes the Pin the Cursor is near to.	
More Options	Opens the full-screen Cursor menu with all the possible options.	
Continue	The Cursor is appended at the end of the route as the new destination. The previous destination is demoted, and becomes the last via point.	
[™] Routing Methods	This button is similar to the opens, and the route is calculated with all the possible route calculation methods (Fast, Short, Economical and Easy). Observe the results, and choose one of the routes to navigate.	
Set as Start	The Cursor becomes the start point of the route. This means that the route is not started from the current GPS position, and Automatic Off-route Recalculation needs to be turned off to keep the selected point as the start point.	
Remove Start	If the Cursor is at or near the selected start point, this button replaces the previous one and deletes the start point from the route. The current GPS position is used again as the start point, and Automatic Off-route Recalculation is re-enabled.	
Save as POI	The Cursor is saved as a user POI. Select the POI group and give a name for the POI, then select a suitable icon, enter a phone number, and additional information if you like.	
Save as Camera	The Cursor is saved as the location of a Road Safety Camera (speed camera or red light camera). A new screen appears where you can set the type of the camera, the direction of the measured traffic, and the speed limit checked for (if applicable).	
	This button is not displayed when GPS position is not available or if you are in certain countries where Road Safety Camera warning is prohibited. Even if the button is available, you are responsible for checking whether it is legal to use this feature at your location.	
Edit Camera	If the Cursor is at or near a Road Safety Camera, this button replaces the previous one, and opens a new screen where you can edit the details of the camera.	

4.1.5 Position menu

When you follow the recommended route on the map (the Cursor is the current GPS position), the Position menu replaces the Cursor menu. It does not contain buttons that modify the current route, as the GPS position is not useful as a route point.



To open the Position menu, tap Position

4.1.6 Route Information screen

The Route Information screen has all the data and some of the functions you need while you navigate. There are two ways to open this screen:





• In Advanced mode, from the Navigation menu tap the following buttons:





In the top section of the screen you see information about the current route. The fields on this screen are continuously updated while you keep the screen open.

When you open the screen, all fields contain information about reaching your final destination. Tap any of the fields to see data on the via points starting from the first one through the final destination again.

You have the following data and functions on this screen:

Name	Description	Function
Route line	The upper part of this screen shows your planned route as a horizontal line. Its leftmost point is the start of the route, the rightmost one is the final destination, and you can see your via point flags along the line, spaced in proportion to their distance.	content of all data fields to via point information.
Estimated Arrival	Shows the estimated arrival time at the final destination of the route based on information available for the remaining segments of the route. The calculation cannot take into account traffic jams and other possible delays.	content of all data fields to via point information.
Distance Left	Shows the distance you need to travel on the route before reaching your final destination.	Tap this field to change the content of all data fields to via point information.
Time Left	Shows the time needed to reach the final destination of the route based on information available for the remaining segments of the route. The calculation cannot take into account traffic jams and other possible delays.	Tap this field to change the content of all data fields to via point information.
Method	This field shows how the route was calculated. It	Tap this field to change the

Name	Description	Function
	either displays the Route Calculation Method or the Vehicle field from the Route Planning options.	content of all data fields to via point information.
Warning icons	In these square fields graphical symbols are displayed in case warnings are attached to the planned route. These are warnings, so icons always show information for the whole route, even if the data fields display values from your current position to a via point only.	Tap any of the icons for an explanation.
Settings		Opens the Route Planning options screen from theSettings menu.
Plan on Map		Opens the map screen designed for route planning.
Skip Next Via	Appears only if at least one via point exists.	Deletes the next via point from the route.
Delete Route	Appears only if there are no via points in the route.	Deletes the active route.

4.1.7 Trip Information screen

The Trip Information screen has both route and travel data you might need during your journey. It can

be opened directly from the Map screen by tapping the Trip Data field (0:02



The fields on this screen are continuously updated while you keep the screen open.

When you open the screen, all route data fields contain information about reaching your final

destination. Tap and the fields concerning your route display data for the next via point. Tap the button repeatedly to toggle between the two options.

You have the following data and functions on this screen:

Name	Description	Function
or P	Shows whether the route data fields show information about the final destination (checkered flag) or about the next via point (yellow flag) .	
Field next to the flag	Shows the name or number of the current street or road.	
Turn Preview	Shows the type and distance of the next route event.	
Compass	Shows the current heading.	Tap this field to show it on the map screen in one of the Trip Data fields.

Name	Description	Function
Speedometer	Shows the current speed both graphically and as a number.	Tap this field to show it on the map screen in one of the Trip Data fields.
Distance Remaining	Shows the distance you need to travel on the route before reaching your final destination.	Tap this field to show it on the map screen in one of the Trip Data fields.
Time Remaining	Shows the time needed to reach the final destination of the route based on information available for the remaining segments of the route. The calculation cannot take into account traffic jams and other possible delays.	Tap this field to show it on the map screen in one of the Trip Data fields.
Arrival Time	Shows the estimated arrival time at the final destination of the route based on information available for the remaining segments of the route. The calculation cannot take into account traffic jams and other possible delays.	Tap this field to show it on the map screen in one of the Trip Data fields.
GPS Time	Shows the current time corrected with time zone offset. The accurate time comes from the GPS satellites, and the time zone information comes from the map or it can be set manually in Regional settings.	Tap this field to show it on the map screen in one of the Trip Data fields.
Altitude	Shows the elevation if it is provided by the GPS receiver.	Tap this field to show it on the map screen in one of the Trip Data fields.
Speed Limit	Shows the speed limit of the current road if the map contains it.	Tap this field to show it on the map screen in one of the Trip Data fields.
Trip Computer		Opens a new screen with three resettable Trip Computers.
Next Via Point		Tap this button to change the content of the Route Data fields to show information about the next via point.
Destination	If you tap the previous button, this one replaces it.	Tap this button and the Route Data fields show information about the final destination again.

Most of the fields on this screen have a symbol next to them. This symbol shows whether the field it is attached to is shown on the map as a Trip Data. It also shows the position of the data as follows:

Symbol	Description
	This value is not shown on the map screen.
	This value appears on the map screen in the Trip Data area. This is the value at the top.
	This value appears on the map screen in the Trip Data area. This is the value in the middle.

Symbol	Description	
	This value appears on the map screen in the Trip Data area. This is the value at the bottom.	

4.1.7.1 Trip Computer screen

The Trip Computer screen provides collected trip data. It can be opened from the Trip Information

Trip Computer screen by tapping

The fields on this screen are continuously updated while you keep the screen open.

You can switch between the trips, pause then resume them, or reset their data.

You have the following functions on this screen:

Button	Description	
Pause	Pauses the trip currently shown on the screen. Values on the screen stop changing.	
Resume	This button replaces the previous one if it has been activated. Tap it to resume collecting trip data.	
Reset	Resets all counters of the currently shown trip. Collecting trip data is restarted only when Clarion Mobile Map receives a position from the GPS.	
 	Cycles through all trips.	

4.1.8 Quick menu

The Quick menu is a selection of controls that are frequently needed during navigation. It can be

opened directly from the Map screen by tapping



If you tap any of the switches in the Quick menu except for the Vehicle type, the Map screen immediately returns. A switch is on if its lamp is lit. The Vehicle type button is different. It is a multivalue button. It opens a list of available choices, and the symbol of the selected vehicle is shown on the button.

Button	Main function (single tap)	Function (tap and hold)
Master Volume slider	Adjusts the sound volume of the device. All sounds of the application are affected.	n/a
+	If you only adjust the volume, you need to use this button to return to the Map screen.	Opens the Navigation menu.
0	Mutes all sounds of Clarion Mobile Map.	Opens Sound settings.

Button	Main function (single tap)	Function (tap and hold)
	Switches between the daytime and night color schemes manually. This will not disable the automatic switching between the two schemes: the other color scheme returns later.	Opens Color Profiles settings.
	3D buildings can be displayed on the map. Use this switch to suppress them temporarily.	Opens 3D Settings.
	Tap this button and select the Vehicle type to be used for route calculation. Otherwise it is selected in Route Planning options in Settings (page 68).	Opens Route Planning options.
	Changing the Vehicle type triggers an automatic route recalculation.	
mir	Turns track log recording on or off otherwise controlled on the Manage Track Logs screen.	Opens Manage Track Logs.
GPS	Opens the GPS Data screen with satellite information, data coming from the GPS receiver, and a shortcut to the GPS Settings screen if needed (GPS receiver detection is automatic).	n/a

4.1.9 GPS Data screen

Tap the following buttons: and then and to see the status of GPS reception.



Icon	Color	Name	Description
<u>* — </u>	Green	GPS position quality indicator	Clarion Mobile Map has a connection to the GPS receiver and GPS position information is available in 3D: Clarion Mobile Map can calculate both your horizontal and vertical GPS position.
<u>* —</u>	Yellow		Clarion Mobile Map has a connection to the GPS receiver and GPS position information is available in 2D: only the horizontal position is calculated, Clarion Mobile Map cannot calculate your vertical GPS position.
*	Gray		Clarion Mobile Map has a connection to the GPS receiver but GPS position information is not available.
*	Red		Clarion Mobile Map has no connection to the GPS receiver.
			Since the device has a built-in GPS

Icon	Color	Name	Description
			receiver, this status should not appear under normal circumstances.
	Green, blinking	GPS connection quality indicator	Clarion Mobile Map is connected to the GPS receiver.
***	Yellow, blinking		Clarion Mobile Map has no connection to the GPS receiver but it is still trying to establish a connection.
	Red, blinking		Clarion Mobile Map has no connection to the GPS receiver and is not trying to establish a connection.
Sky view circle			The virtual sky shows the visible part of the sky above you, with your position as the center. The satellites are shown at their current positions. The GPS receives data from both the green and yellow satellites. Signals from the yellow satellites are only received, while green ones are used by the GPS receiver to calculate your current location.
n/a	Coordinates		Your current GPS position in WGS84 format.
n/a	Status bar for the satellites		Dark bars are for the yellow and lit bars are for the green satellites. The more satellites your GPS tracks (the green ones), the better is your calculated position.

4.2 Find menu

Select the destination of your route. Tap the following buttons: Menu ,



Button	Description	Reference
Find Address	If you know at least a part of the address, this is the quickest way to find the location.	page 29
Find POI	You can select your destination from the thousands of POIs included with Clarion Mobile Map or from the ones you have previously created.	
History	The destinations that you have already entered in Clarion Mobile Map are available in the History list.	page 38
Find	You can select your destination by entering its coordinates.	page 38
Favorites	You can select as your destination a location that you have already saved as a Favorite.	page 36

Button	Description	Reference
Plan on Map	Opens a special 2D map screen optimized for route planning. Only the Zoom in and Zoom out buttons and the route modification buttons of the Cursor menu appear.	

4.3 Route menu





4.5 Route IIIe	ııu		
Save, load and edit your routes. Tap the following buttons:			
Button	Description	Reference	
Route Info	Opens a screen with useful route data.	page 54	
I Itinerary	You can browse the driving instructions that Clarion Mobile Map follows during navigation. You can exclude maneuvers or streets to adjust the route to your preferences.	page 23	
Edit Route	You can modify the route: remove route points or change their order.	page 40	
Delete Route	Erase the active route with all its route points (start point, via points and destination). If you later decide that you need the same route, you will have to rebuild it from scratch.	page 42	
Save Route	You can save the active route for later use.	page 44	
Load Route	You can load a previously saved route for navigation.	page 44	
Settings	Opens the Route settings screen with controls to modify the vehicle, the road types used for route calculation, or the route calculation method.	page 68	
Fly Over	You can run a demonstration of the route at high speed.	page 24	
Simulate	You can run a demonstration of the route at normal speed.	page 24	

4.4 Manage menu





You can manage the content that Clarion Mobile Map stores. Tap the following buttons:

Button	Description	Reference
Saved Routes	Renaming or deleting saved routes	page 61
History	Deleting History items	page 62
Track Logs	Recording, simulating, renaming or deleting track logs, assigning color to them to be shown on the map	page 62
Favorites	Renaming or deleting Favorites	page 63
POI	Creating, updating or deleting POIs	page 63
	Creating, updating or deleting POI groups	
	Modifying POI visibility settings	
Saved Search Criteria	Creating, renaming or deleting Saved Search Criteria	page 64
User Data Management	You can manage the data you have saved (e.g. POIs, Favorites or History) and the settings you have made in the program.	page 65

4.4.1 Manage Saved Routes





You can manage the previously saved routes. Tap the following buttons:

Saved	Routes	
	Butt	on

Button	Description
Button with the name of the saved route	Opens the selected route for editing.
*	Deletes the selected route.
Clear All	Clears the list of saved routes.
≺ ≻	Moves between pages for additional list items.

4.4.2 Manage History







You can manage the list of locations you used lately. Tap the following buttons:

Button	Description
*	Deletes the selected item in the History.
Clear History	Deletes the entire History.
◀, ▶	Moves between pages for additional list items.

4.4.3 Manage Track Logs

You can record Track Logs, then play them back, display them on the map, and view their details.



Button	Description
Record	Starts recording the track that you drive. (You can also start recording a track log in the Quick menu.)
Stop Recording	Stops the ongoing Track Log recording. (You can also stop track log recording in the Quick menu.)
Button with the name of the track log	Shows the details of the selected Track Log.
	Starts a simulated playback of the selected Track Log on the map.
◀, ➤	Moves between pages for additional list items.

When track log details are shown:

Button	Description
Button with the name of the Track Log	Opens a keyboard screen to let you rename the Track Log.
	Tap this button to hide the Track Log on the map. No color will be assigned to the Track Log.
	Tap one of the colored buttons to assign a color to the Track Log. The Track Log will be shown on the map with this color.
Fit to Screen	The map returns with the Track Log. The map is scaled to show the whole Track Log.
Delete	Deletes the selected Track Log.
Export	Saves the Track Log on the inserted memory card in GPX format.

4.4.4 Manage Favorites



Favorites

You can manage the list of your Favorites. Tap the following buttons:

Button	Description
Button with the name of the Favorite	Opens the selected Favorite for editing.
*	Deletes the selected item in the list of Favorites.
Clear All	Clears the list of Favorites.
⋖ , >	Moves between pages for additional list items.

4.4.5 Manage POIs

You can manage your POIs, and set POI visibility for both your POIs and the ones that came with the

product. Tap the following buttons: Menu, Menae,

Button / Icon	Description
Button with the name of the POI group	Opens the list of the subgroups of this POI group. The new list behaves the same as this one. $ \\$
Button with the name and address of a POI item	Opens the selected POI for editing. Only the POIs you have created appear in this list.
Edit	Opens the selected POI group for editing.
Му РОІ	Tap to filter the list to contain only the POIs that you saved.
All	Tap to see all POIs in the list.
New Group	Creates a new POI group at the given group level.
< , ➤	Moves between pages for additional list items.
	This POI group is not shown on the map.
	This POI group and all its subgroups are shown on the map.
0	This POI group and some of its subgroups are shown on the map.
0	This POI group contains POIs that you saved.

When a POI group is open for editing:

В	utton	Description
Off		Items in the POI group will not be shown on the map.
Close	Medium	The distance buttons set the zoom level from which the items in the POI group will be shown on the map.

Button	Description
Same Visibility in Subgroups	Subgroups under the edited POI group will inherit the visibility settings of the POI group.
Button with the icon of the POI group	Tap this button to select a new icon for the POI group.
Remove	Deletes the edited POI group. You are only allowed to remove POI groups that you have created.

When a POI item is open for editing:

Button	Description
Button with the name of the POI	Tap this button to rename the POI.
Button with the icon of the POI	Tap this button to select a new icon for the POI.
ħ	Tap this button to modify the location of the POI. Select a new location on the map and tap to relocate the POI.
2	Tap this button to enter a telephone number for the POI.
i	Tap this button to enter additional information for the POI.
Delete	Tap this button to delete the selected POI.
Change Group	Tap this button to move the POI to another POI group or subgroup.

4.4.6 Manage Saved Search Criteria

You can manage the list of search criteria previously saved to easily find frequently searched POI



Button	Description
Button with the name of the Saved Search Criteria	Tap to rename the saved query.
*	Deletes the selected item in the list.
Clear All	Deletes the entire list.
⋖ , >	Moves between pages for additional list items.
<add new="" search=""></add>	Tap to save a new search criteria. Similar to how you search for a POI, select the search reference first, then select the POI group or subgroup to search in.

4.4.7 User Data Management

You can manage the data you have saved (e.g. POIs, Favorites or History) and the settings you have

made in the program. Tap the following buttons: Menu



Button	Description
Remove Pins	Man leastings can be marked with Discusing the
	Map locations can be marked with Pins using the button in the Cursor menu. Tap this button to remove all your Pins from the map.
Backup User Data	All user data and the current settings will be saved on the inserted memory card. There is always one backup file. If you perform a backup later, the
	previous backup will be overwritten with the new information.
Restore User Data	All user data and settings will be overwritten with the information stored in the backup file. Data and settings created after the latest backup will be lost.
Delete User Data	All user data will be deleted, and settings will return to their factory defaults. The application needs to restart.
Reset All Settings	All settings will return to their factory defaults, but no user data will be deleted. The application needs to restart.

4.5 Settings menu

You can configure the program settings, and modify the behavior of Clarion Mobile Map. Tap the

following buttons: Menu , Settings

The Settings menu has two pages of submenus. Tap _____ to access the other options.



Button	Description	Reference
Map Screen	You can fine-tune the appearance and content of the Map screen. $ \\$	page 66
Sound	You can adjust the sounds of Clarion Mobile Map.	page 67
Route Planning	These settings determine how routes will be calculated.	page 68
Regional	These settings allow you to customize the application for your local language, measurement units, time and date settings and formats, as well as to choose the voice guidance profile you prefer.	page 69

Button	Description	Reference
Navigation	You can control how Clarion Mobile Map behaves during navigation.	page 70
Warnings	You can enable some useful warnings, and disable the touch screen in a moving vehicle with Safety Mode.	page 71
Menu	You can modify the look and behavior of the Menu screens.	page 72
Device	You can fine-tune device related settings in this menu.	page 72
Track Logs	You can set up automatic Track Log saving and fine-tune related settings.	page 73
About	This screen has no navigation feature. It merely provides information about the maps and licenses included with your navigation system.	
Simple Mode	You can switch to Simple mode. In Simple mode only a few of the above settings are available. The rest of the settings are set to values that are optimal for typical use.	page 10

4.5.1 Map Screen settings



You can fine-tune the appearance and content of the Map screen. Tap the following buttons:





Button	Description
3D Settings	Use 3D settings to determine which of the present 3D objects are shown on the map, and adjust the level of 3D visual detail. The options are as follows:
	 Landmarks: Landmarks are 3D artistic or block representations of prominent or well-known objects. 3D landmarks are only available in selected cities and countries.
	Elevated Roads: Complex intersections and vertically isolated roads (such as overpasses or underground tunnels) are displayed in 3D.
	Building Visibility: Full 3D city building data that represents actual building size and position on the map. Building data is limited to the city centers of major cities in the US and Europe.
	Terrain Detail Level: 3D terrain map data shows changes in terrain, elevations or depressions in the land when you view the map, and use it to plot the route map in 3D when you navigate.
Color Profiles	Clarion Mobile Map is able to show the map and the menus in different colors during the day and during the night. Select the color profiles to be used in each mode, and select the automatic or manual switching between the daytime and night color profiles.

Button	Description
Elevation on 2D Map	2D maps can also display 3D information. These top-down maps can display elevation by colors and shading.
Street Names During Navigation	Street names and POI icons can be disturbing on the map during navigation. With this switch you can suppress these map elements when Clarion Mobile Map is following your position on the map. If you move the map, both the street names and POI icons reappear immediately.
Lane Information	Some maps contain lane information to help you position your car in the upcoming intersection. This setting tells Clarion Mobile Map whether to display this information at the top or at the bottom of the map.
Interrupt AV	When Clarion Mobile Map is working in the background, the map can be displayed on the screen when approaching a maneuver.

4.5.2 Sound settings





You can adjust the sounds of Clarion Mobile Map. Tap the following buttons:



Button	Description
Master Volume	Use the switch to mute all sounds of the device and then to re-enable them again. The position of the slider determines the volume level.
Voice Guidance Volume	The slider adjusts the loudness of voice prompts. In its leftmost position, the voice guidance is suppressed; in its rightmost position, the master volume applies.
Key Sounds	Key sounds provide audible confirmation of either pressing hardware buttons or tapping the touch screen.
	The switch turns key sounds on or off. Key sounds are played at the master volume level.
Dynamic Volume	When driving at high speed, the noise in the car may be too loud to clearly hear the voice guidance and other sounds. Using Dynamic Volume you can instruct Clarion Mobile Map to increase the volume when your speed exceeds a certain minimum, and reach its highest volume at the given maximum speed.
Trigger Tone	A special sound played before voice instructions.

4.5.3 Route Planning options





These settings determine how routes will be calculated. Tap the following buttons:

A Ro	ute P	lanning	

Button	Description
Vehicle	You can set the type of vehicle you will use to navigate the route. Based upon this setting, some of the road types can be excluded from the route, or some of the restrictions may not be taken into account in route calculation.
Road Types Used for Route Planning	To let the route fit your needs, you can also set which road types are to be considered for or to be excluded from the route if possible.
	Excluding a road type is a preference. It does not necessarily mean total prohibition. If your destination can only be accessed using some of the excluded road types, they will be used but only as much as necessary. In this case a warning icon will be shown on the Route Information screen, and the part of the route not matching your preference will be displayed in a different color on the map.
Route Calculation Method	You can choose from different route types. The routing method can be changed temporarily while creating the route: when the destination is selected, tap in the Cursor menu.

Vehicle types:

- Car
- Taxi
- Bus
- Emergency vehicles

Road Types Used for Route Planning:

Type	Description
Freeways	You might need to avoid freeways when you are driving a slow car or you are towing another vehicle.
Unpaved roads	Clarion Mobile Map excludes unpaved roads by default: unpaved roads can be in a bad condition and usually you cannot reach the speed limit on them.
Toll roads	By default Clarion Mobile Map includes toll roads (pay roads where there is a per-use charge) in the routes. If you disable toll roads, Clarion Mobile Map plans the best toll-free route.
Charge roads	Charge roads are pay roads where you can purchase a pass or vignette to use the road for a longer period of time. They can be enabled or disabled separately from toll roads.

Type	Description
Permit needed	You might need a permit or permission from the owners to use certain roads or to enter certain areas. Clarion Mobile Map excludes these roads from the route calculation by default.
Ferries	Clarion Mobile Map includes ferries in a planned route by default. However, a map does not necessarily contain information about the accessibility of temporary ferries. You might also need to pay a fare on ferries.
Cross-border planning	In some cases the route calculated according to your other navigation and route preferences would lead through another country. If you wish to always stay within the same country, turn this option off.
Carpool lanes	This control appears only when navigating in the USA. You should check whether you are allowed to use carpool lanes before enabling this road type.

Route Calculation Method types:

Option	Description
Fast	Gives the quickest possible route if you can travel at or near the speed limit on all roads. Usually the best selection for fast and normal cars.
Short	Gives a route that has the smallest total distance of all possible routes between the route points. It can be practical for slow vehicles.
Economical	Combines the benefits of Fast and Short: Clarion Mobile Map calculates as if it were calculating the Fast route, but it takes other roads as well to save fuel.
Easy	Results in a route with fewer turns. With this option, you can make Clarion Mobile Map to take, for example, the freeway instead of series of smaller roads or streets.

4.5.4 Regional settings

These settings allow you to customize the application for your local language, measurement units, time and date settings and formats, as well as to choose the voice guidance profile you prefer. Tap

Regional

the following buttons: Menu , Settings

Button	Description
Program Language	This button displays the current written language of the Clarion Mobile Map user interface. By tapping the button, you can select a new language from the list of available languages. The application will restart if you change this setting; you are asked to confirm this.
Voice Profile	This button shows the current voice guidance profile. By tapping the button, you can select a new profile from the list of available languages and speakers. Tap any of these to hear a sample voice prompt. Just tap OK when you have selected the new spoken language.

Button	Description
Units	You can set the distance units to be used by the program. Clarion Mobile Map may not support all the listed units in some voice guidance languages. If you select a measurement unit not supported by the chosen voice guidance language, a warning message will appear.
Set Date & Time Format	You can set the date and time format. Various international formats are available.
Time and Time Zone Settings	You can access time and time zone settings. Clarion Mobile Map helps you with correcting the device time to the ever accurate GPS time. Clarion Mobile Map can also help you set the time zone based on your current GPS position.

Time and Time Zone Settings:

Button	Description
Auto Time Correction to GPS	Use this feature to synchronize the clock of your device to the highly accurate time provided by the GPS receiver.
Use Auto Time Zone	Use this feature to synchronize the time zone of the clock of your device to the time zone based on your current GPS position. This is useful if you travel abroad.
Set Time Zone	Set time zone manually if you do not want to synchronize the time zone automatically. This allows you to use Auto Time Correction and apply a time zone offset to obtain the desired time.
Compare GPS and device times	The current time of the GPS receiver and the device clock are displayed. Please note that the GPS clock is only available with GPS reception. This allows you to check whether any correction is needed.

4.5.5 Navigation settings



You can control how Clarion Mobile Map behaves during navigation. Tap the following buttons:





Button	Description
Keep Position on Road	This feature allows car drivers to always correct GPS position errors by matching the vehicle position to the road network.
	By turning off this feature you also turn off the GPS position error filtering. The position shown on the map will be subject to all position errors and position fluctuations.
Off-route Recalculation	This switch tells Clarion Mobile Map whether to automatically recalculate the route when you deviate from it. If this feature is turned off, you need to initiate route recalculation manually otherwise navigation will be stopped until you return to the originally recommended route.
	Setting another point than the current GPS position as the start point

Button	Description
	of the active route will automatically disable this feature.
Restore Lock-to-Position	If you have moved or rotated the map during navigation, this feature moves the map back to your current GPS position and re-enables automatic map rotation after the given period of inactivity.
Automatic Overview	This feature switches the map view to Overview mode when the next route event is at a distance. Overview is a zoomed out 2D view to let you see the surrounding area. You have the following controls for Automatic Overview:
	 Turn Distance for Overview: The map view will be switched to Overview mode if the next route event is at least as far as this value.
	Default Zoom Level: Overview mode will appear with this zoom level. You can scale the map in Overview mode but next time Overview appears again, this zoom level will be applied.

4.5.6 Warning settings

You can enable some useful warnings, and disable the touch screen in a moving vehicle with Safety

Warnings

Mode. Tap the following buttons: Menu

Button	Description
Warn When Speeding	Maps may contain information about the speed limits of the road segments. Clarion Mobile Map is able to warn you if you exceed the current limit. This information may not be available for your region (ask your local dealer), or may not be fully correct for all roads in the map This setting lets you decide whether you wish to receive the warnings You can set the relative speeding level at which the application warns you (100% represents the current speed limit):
	In Built-up Areas: in cities and cities
	Elsewhere: at all other locations
	The warning itself is a voice message that is played using the selected voice guidance profile.
Speed Camera Warning	This feature allows you to receive a warning when approaching a Road Safety Camera. You must ensure on your own liability that using this feature is legal in the country where you intend to use it. You have the following options:
	 Audible Warning: beeps can be played while you are approaching the camera, or just alert sounds if you exceed the speed limit while approaching one of these cameras.
	 Visible Warning: the type of the camera and the monitored speed limit appear on the Map screen while you are approaching one of these cameras.
	This button is not displayed when GPS position is not available or i you are in certain countries where Road Safety Camera warning is prohibited. Even if the button is available, you are responsible for

Button	Description
	checking whether it is legal to use this feature at your location.
Safety Mode	Safety Mode disables the touch screen above 10 km/h (6 mph) to keep your attention on the road. While driving, you will not be able to set a new destination or to change settings. The only screen control that remains enabled is the gesture that puts you back on the Map screen.

4.5.7 Menu settings



You can modify the look and behavior of the Menu screens. Tap the following buttons:



Button	Description
Animation	You can activate and deactivate the Menu animations. When animation is turned on, buttons on Menu and keyboard screens appear in an animated way.
Background	You can choose the image to be used as the menu background image.

4.5.8 Device settings





You can fine-tune device related settings in this menu. Tap the following buttons:



Button	Description
Screen Calibration	You can fine-tune the position of the screen content on the display. Tap this button, use the arrows to reposition the application window, and then tap
GPS Antenna	This field indicates whether the external GPS antenna is connected to your Clarion NP509.

4.5.9 Track Log settings

You can set up automatic Track log saving, and fine-tune related settings. Tap the following buttons:







Button	Description
Update Interval	This determines how often track points will be saved. Position information is normally received once a second from the GPS. If you do not need such a detailed log, you can increase this number to save track log space.
Enable Auto-saving	When auto-saving is enabled, you do not need to turn track log saving on and off manually. Clarion Mobile Map will automatically start recording the track log as soon as GPS position is available.
Track Log Database Size	This figure shows how much memory is used by the automatically saved track logs.
Track Logs Max. Size	You can set the maximum database size for the automatically saved track logs. When the limit is reached, the oldest automatically saved track logs will be deleted.
Create NMEA/SIRF Log	Independently of the normal track log, you can instruct Clarion Mobile Map to record the native GPS data received from the GPS device. These logs are saved as separate text files on the memory card, and they cannot be shown or replayed in Clarion Mobile Map.

5 Glossary

2D/3D GPS reception

The GPS receiver uses satellite signals to calculate its (your) position and needs at least four signals to give a three-dimensional position, including elevation. Because the satellites are moving and because objects can block the signals, your GPS device might not receive four signals. If three satellites are available, the receiver can calculate the horizontal GPS position but the accuracy is lower and the GPS device does not give you elevation data: only 2D reception is possible.

Active route

The currently navigated route. You can save and load routes in Clarion Mobile Map, but only one route can be active at any given time, and it is always active until you delete it, reach your destination or you quit Clarion Mobile Map. See also: Route.

City Center

The City Center is not the geometric center of the city but an arbitrary point the map creators have chosen. In cities and villages, it is usually the most important intersection; in larger cities, it is an important intersection.

GPS accuracy

Several factors have impact on the deviation between your real position and the one given by the GPS device. For example, signal delay in the ionosphere or reflecting objects near the GPS device have a different and varying impact on how accurately the GPS device can calculate your position.

Map

Clarion Mobile Map works with digital maps which are not simply the computerized versions of traditional paper maps. Similarly to the paper road maps, the 2D mode of digital maps show you streets, roads, and elevation is also shown by colors.

In 3D mode, you can see the altitude differences, for example valleys and mountains, elevated roads, and in selected cities 3D landmarks and 3D buildings are also displayed.

You can use digital maps interactively: you can zoom in and out (increase or decrease the scale), you can tilt them up and down, and rotate them left and right. In GPS-supported navigation, digital maps facilitate route planning.

North-up map orientation

In North-up mode the map is rotated so its top always faces North. This is the orientation in 2D map view mode and in Overview mode. See also: Track-up map orientation.

Overview mode

You can instruct Clarion Mobile Map to automatically switch to Overview mode if the next route event is in a distance. In Overview mode the map is shown in 2D but scaled down to a predefined zoom level. When you approach the next route event, the previous 2D or 3D map view returns automatically.

Route

A series of destinations to be reached one after the other. A simple route contains one start point and only one destination. Multi-point routes contain one or more via points (intermediate destinations). The last route point is the final destination and the route is cut into different legs (from one destination to the next).

Scheme

Clarion Mobile Map comes with different color schemes for the map for daytime or night use. Schemes are custom graphic settings for the map and they can have different colors for streets, blocks or surface waters in 2D and 3D modes, and they display shades or shadows in different ways in 3D mode

One daytime scheme and one night scheme is always selected. Clarion Mobile Map uses them when it switches from day to night and back.

Track-up map orientation

In Track-up mode the map is rotated so its top always points in the current driving direction. This is the default orientation in 3D map view mode. See also: North-up map orientation.

Road Safety Camera

A special POI type for speed cameras and red light cameras. Different data sources are available, and you can also mark the position of a Road Safety Camera on the map.

You can configure Clarion Mobile Map to warn you when you approach one of these cameras.

Detecting the location of Road Safety Cameras is prohibited in certain countries. It is the sole responsibility of the driver to check whether this feature can be used during the trip.

6 End User License Agreement

- 1 The contracting parties
- 1.1 This Agreement has been entered into by and between Nav N Go Kft. (registered seat: 23 Bérc utca, H-1016 Budapest, Hungary; Company reg.no.: 01-09-891838) as Licensor (hereinafter: Licensor) and You as the User (hereinafter: User; the User and the Licensor jointly referred to as: Parties) in subject of the use of the software product specified in this Agreement.
- 2 Conclusion of the Agreement
- 2.1 The Parties hereby acknowledge that this Agreement shall be concluded by implicit conduct of the Parties without signing the Agreement.
- 2.2 The User hereby acknowledges that following the lawful acquisition of the software product constituting the object of this Agreement (Section 4), any degree of use, installation into a computer or other hardware, installation of such hardware into a vehicle, pressing of the "Accept" button displayed by the software during installation or use (hereinafter referred to as Use) shall mean that the User has accepted the terms and conditions of this Agreement as legally binding.
- 2.3 This Agreement shall by no means authorise use of the software product by those persons having unlawfully acquired the software product or having unlawfully installed it on a computer or in a vehicle.
- 3 Relevant laws and regulations
- 3.1 To all issues not regulated by this Agreement, the laws of the Republic of Hungary, with specific reference to Act IV of 1959 on the Civil Code and to Act LXXVI of 1999 on Copyrights shall apply.
- 3.2 The original language version of this Agreement is the Hungarian version. This Agreement has versions in other languages as well. In case of dispute the Hungarian version shall prevail.
- 4 Object of the Agreement
- 4.1 The object of this Agreement shall be the navigation guidance software product of Licensor (hereinafter referred to as the Software Product).
- 4.2 The Software Product shall include the operating computer program, its complete documentation, the map database pertaining thereto and any third-party content and services accessible through the Software Product (hereinafter: Database).
- 4.3 Any form of display, storage, coding, including printed, electronic or graphic display, storage, source or object code, or any other as yet undefined form of display, storage, or coding, or any medium thereof shall be deemed parts of the Software Product.
- 4.4 Error corrections, additions, updates used by the User following the conclusion of this Agreement shall also be deemed parts of the Software Product.
- 5 Rights under copyright
- 5.1 Unless otherwise provided by law or contractual provisions, the Licensor is the sole and exclusive owner of all material copyrights vested in the Software Product.
- 5.2 Copyrights extend to the whole Software Product and to its parts separately as well.
- 5.3 The owner(s) of the copyrights of the Database forming part of the Software Product is (are) the natural person(s) or corporate entity(ies) listed in the Appendix to this Agreement or in the "About" menu item of the operating computer program (hereinafter referred to as Database Owner). The user's manual of the Software Product includes the name of the menu option where all the owners of the Database items are listed. The Licensor hereby states that it has obtained sufficient usage and representation rights from the Database owners in order to utilize the Database, to offer it for utilization and to transfer it for utilization as set forth in this Agreement.
- 5.4 Pursuant to this Agreement, all rights vested in the Software Product shall remain in the ownership of the Licensor, except for those to which the User is entitled under law or by virtue of this Agreement.
- 6 Rights of the User
- 6.1 The User is entitled to install the Software Product into one hardware device (desktop, handheld, portable computer, navigation device), and to run and use one copy of the Software Product or a preinstalled copy of the Software Product thereon.

6.2 The User is entitled to make one backup copy of the Software Product. However, if the Software Product operates after installation without the use of the original media copy, then the original media copy shall be deemed to be a backup copy. In all other cases, the User is only entitled to use the backup copy if the original media copy of the Software Product has been ascertainably and unequivocally rendered unsuitable for its lawful and intended use.

7 Limitations of use

- 7.1 The User is not entitled
- 7.1.1 to duplicate the Software Product (to make a copy thereof);
- 7.1.2 to lease, rent or lend it or to transfer it to a third person for any reason;
- 7.1.3 to translate the Software Product (including translation (compilation) to other programming languages);
- 7.1.4 to decompile the Software Product:
- 7.1.5 to evade the protection of the Software Product or to modify, circumvent or obviate such protection through technological or by any other means;
- 7.1.6 to modify, extend, transform the Software Product (in whole or in part), to separate it into parts, combine it with other products, install it in other products, utilize it in other products, not even for the purpose of achieving interoperability with other devices;
- 7.1.7 apart from using the computer program, to obtain information from the Database as a part of the Software Product, to decompile the Database, to use, copy, modify, extend, transform the Database in whole or in part or the group of data stored therein, or to install it in other products or otherwise, utilize it in other products or to transfer it, not even with the aim of achieving interoperability with other products.
- 7.2 The User may only use the contents available through the Software Product and provided by third parties and the data received through the services provided by third parties (including but not limited to the traffic data received from the RDS TMC traffic information service) for his/her own personal benefit and at his/her own risk. It is strictly prohibited to store, to transfer or to distribute these data or contents or to disclose them in full or in part to the public in any format or to download them from the product.
- 8 No warranty or limitation of responsibility
- 8.1 The Licensor hereby informs the User that although the greatest care was taken in producing the Software Product, given the nature of the Software Product and its technical limitations, the Licensor does not provide a warranty for the Software Product being completely error-free, and the Licensor is not bound by any contractual obligation whereby the Software Product obtained by the User should be completely error-free.
- 8.2 The Licensor does not warrant that the Software Product is suitable for any purpose defined either by the Licensor or the User, and does not warrant that the Software Product is capable of interoperating with any other system, device or product (e.g., software or hardware).
- 8.3 The Licensor does not assume any responsibility for damages incurred due to an error in the Software Product (including errors of the computer program, the documentation and the Database).
- 8.4 The Licensor does not assume any responsibility for damages incurred due to the Software Product not being applicable for any defined purpose, or due to the error or incompatibility of the Software Product with any other system, device or product (e.g. software or hardware).
- 8.5 The Licensor also draws the attention of the User to the fact that, when using the Software Product in any form of vehicle, observing the traffic regulations and rules (e.g. use of obligatory and/or reasonable and suitable security measures, proper and generally expected care and attention in the given situation, and special care and attention required due to the use of the Software Product) is the exclusive responsibility of the User. The Licensor shall not assume any responsibility for any damages occurred in relation to use of the Software Product in a motor vehicle.
- 8.6 By concluding the Agreement, the User shall, in particular, acknowledge the information stated in Section 8 above.
- 9 Sanctions

- 9.1 The Licensor hereby informs the User that, if the Licensor finds its rights under the Copyright Act to be breached, the Licensor may
- 9.1.1 seek judicial recognition of this breach;
- 9.1.2 demand that the breach cease and order the person in breach to refrain from continuing such actions:
- 9.1.3 demand that the person under breach give proper compensation (even by way of publicity at the expense of the person in breach);
- 9.1.4 claim the return of the increase of assets due to the breach:
- 9.1.5 demand the cease of the wrongful action and, demand restitution to its state before the breach was committed at the expense of the person in breach, and may demand the destruction of instruments and materials used to commit the breach as well as of the products created by the breach:
- 9.1.6 claim for damages.
- 9.2 The Licensor hereby also informs the User that the breach of copyrights and related rights is a crime under Act IV of 1978 on the Hungarian Criminal Code, which may be sentenced of two years in prison in basic cases and up to eight years in prison in aggravated cases.
- 9.3 Contents and services provided by third parties

The Licensor hereby excludes any liability of its own for the Database in the Software Product and for any content or service provided by a third party by using the Database. The Licensor does not warrant the quality, suitability, accuracy, fitness for a specific purpose or territorial coverage of the product or service or the availability of the service, and it specifically excludes any liability for the suspension of the service, and any damage arising in relation to the service or for complete cancellation of the service.

The relevant information and data in connection with the contents and services provided by third parties are available at www.navngo.com. The User hereby acknowledges that the contents and services provided by third parties may only be used at the risk of the User and for the personal benefit of the User.

9.4 Contents and services provided by the Licensor or an agent of the Licensor

The Licensor or a contractual partner may offer various products and services to the User through www.naviextras.com. The User may only use these services when the User has read and understood the relevant end user license agreement(s) at www.naviextras.com and the User is obliged to use the services in line with the terms and conditions thereof.

9.5 The parties hereby agree that - depending on the nature of the dispute - either the Pest Central District Court (Pesti Központi Kerületi Biróság) or the Metropolitan Court of Budapest (Fővárosi Biróság) will have exclusive jurisdiction to rule on any disputes arising in connection with this Agreement.